

Part No. IA004006

Jul 2012

# USER'S MANUAL

---

## Regulated DC Power Supply PWR Series

400 W Type


**PWR400L**      **PWR400M**      **PWR400H**

800 W Type

**PWR800L**      **PWR800M**      **PWR800H**

1600 W Type

**PWR1600L**      **PWR1600M**      **PWR1600H**



Microsoft and Windows are registered trademarks of Microsoft Corporation in the United States and/or other countries.

Other company names and product names used in this manual are generally trademarks or registered trademarks of the respective companies.

Reproduction and reprinting of this operation manual, whole or partially, without our permission is prohibited.

Both unit specifications and manual contents are subject to change without notice.

## How to read this manual

This manual is intended for first-time users of the PWR. It gives an overview of the regulated DC power supply and describes various settings, operation, maintenance, safety precautions, etc. Read this manual thoroughly to use the functions of the PWR effectively. You can also review this manual when you are confused about an operation or when a problem occurs.

This manual is designed to be read from beginning to end. We recommend that you read the manual thoroughly from the beginning.

## Related manuals

For details on the Power Supply Controller, see the operation manual of the respective product. For connection to a Power Supply Controller and device messages, refer to the “Connecting & Programming Guide” [index.html] in the CD-ROM that came with the PIA4800 series.

## Intended readers of this manual

This manual is intended for users of the PWR regulated DC power supply series or persons teaching other users on how to operate them. The manual assumes that the reader has knowledge about electrical aspects of regulated DC power supplies.

---

## Notations used in the manual

The PWR regulated DC power supply series is also simply referred to as the PWR series in this manual.

The following markings are used in the explanations in the text.

### WARNING

Indicates a potentially hazardous situation which, if ignored, could result in death or serious injury.

### CAUTION

Indicates a potentially hazardous situation which, if ignored, may result in damage to the product and other property.

### NOTE

Indicates information that you should know.

### DESCRIPTION

Explanation of terminology or operation principle.

### See

Indicates reference to detailed information.

### C-x:x

The first two characters “C-” indicate a configuration setting, and the next one-digit number indicates the CONFIG parameter number. The character after the colon indicates the selected setting.

### SHIFT+switch name (marked in blue)

Indicates an operation in which a switch marked in blue is pressed while holding down the SHIFT switch.

# Contents

How to read this manual	i
Front panel	vi
Rear panel	viii

## Chapter 1 General Description

1.1 About This Manual	1-2
1.2 Options	1-3
1.3 Rack Mounting the Product	1-6
1.4 Remote Control Overview	1-8

## Chapter 2 Basic Operation

2.1 Measured Value Display and Setting Display	2-2
2.2 Panel control	2-4
2.3 Output Operation	2-6
2.4 Description of Operation	2-7
2.4.1 Constant Voltage (CV) and Constant Current (CC) Power Supplies	2-8
2.4.2 Extended operating area (L type only)	2-11
2.5 Using the PWR as a CV or CC Power Supply (Setting the Output Voltage and Current)	2-13
2.6 Protection Function and Alarm	2-15
2.6.1 Alarm occurrence and release	2-15
2.6.2 Overvoltage protection (OVP) and overcurrent protection (OCP)	2-17
2.6.3 Other Protection Functions	2-21
2.7 CONFIG Settings	2-23
CONFIG parameter details	2-25
2.8 Lock Function	2-28
2.9 Remote Sensing Function	2-29
Connecting the sensing cable	2-29
2.10 Factory Default Settings	2-32

---

## Chapter 3 External Control

3.1	Overview of External Control	3-2
3.2	J1 connector	3-2
	J1 connector arrangement	3-3
3.3	Output Terminal Insulation	3-6
	3.3.1 When the Output Terminal Is Not Grounded (Floating)	3-7
	3.3.2 When the Output Terminal Is Grounded	3-8
3.4	Output Voltage Control	3-10
	3.4.1 External Voltage (Vext) Control	3-10
	3.4.2 External Resistance (Rext) Control	3-12
3.5	Output Current Control	3-14
	3.5.1 External Voltage (Vext) Control	3-14
	3.5.2 External Resistance (Rext) Control	3-16
3.6	Controlling the Output On/Off	3-18
3.7	Shutdown Control	3-21
3.8	External Monitoring	3-23
	External monitoring of the output voltage and output current	3-23
	External monitoring of the operating status	3-24

## Chapter 4 Parallel/Series Operation

4.1	Master-Slave Series Operation (L Type Only)	4-2
	4.1.1 Functions (Series Operation)	4-2
	4.1.2 Connection (Series Operation)	4-4
	Connecting the signal wires (series operation)	4-4
	Load connection (series operation)	4-5
	4.1.3 Setup (Series Operation)	4-6
	4.1.4 Procedure (Series Operation)	4-7
4.2	Master-Slave Parallel Operation	4-8
	4.2.1 Functions (Parallel Operation)	4-8
	4.2.2 Connection (Parallel Operation)	4-11
	Connecting the signal wires (parallel operation)	4-11
	Connecting the load (parallel operation)	4-12
	4.2.3 Setup (Parallel Operation)	4-14
	4.2.4 Procedure (Parallel Operation)	4-15



---

## Chapter 5 Maintenance

5.1	Inspection	5-2
5.1.1	Cleaning	5-2
	Cleaning the Panels	5-2
	Cleaning the dust filter	5-3
5.2	Calibration	5-5
5.2.1	Calibration Overview	5-5
5.2.2	Voltage Calibration	5-6
5.2.3	Current Calibration	5-9
5.3	Troubleshooting	5-12

## Chapter 6 Specifications

	Common specifications	6-3
	Model-specific specifications (L type)	6-8
	Model-specific Specifications (M type)	6-12
	Model-specific specifications (H type)	6-14
	Outline Drawing	6-16

## Index

1

2


3

4

5

6

## Front panel



PWR400L example



STUP: See the setup manual.

No.	Name		Description	See
		+SHIFT		
1	OUTPUT		Output on/off switch.	p.2-6
2	Air inlet (louver)		Air inlet for internal cooling. A dust filter is built in.	p.5-3
3	SHIFT		Switch for calling up the functions marked in blue characters.	p.ii
4	CONFIG		Switch for setting various conditions concerning the operation.	p.2-23
5	LOCK		Switch with an LED for locking the operations other than turning the output on/off.	p.2-28
6	ADDRESS		Switch for setting the node address for remote control.	-
7	POWER		POWER switch. Press the (I) side to turn the power on and the (O) to turn the power off.	STUP
8	VOLTAGE		Switch for selecting coarse or fine (the digit) when setting the voltage.	p.2-4
		PWR DSPL	Displays the output power on the voltmeter.	p.2-2
9	CURRENT		Switch for selecting coarse or fine (the digit) when setting the current.	p.2-4
		PWR DSPL	Displays the output power on the ammeter.	p.2-2
10	SET		Switch with an LED for setting and checking the output voltage or output current	p.2-2
11	OVP		OVP (overvoltage protection) trip voltage display.	p.2-17
		OCP	OCP (overcurrent protection) trip current display.	
12	Setting knob		Knob for changing the setting. Press the knob to switch between coarse and fine.	p.2-4
13	DC OUTPUT		Output terminal with a cover on the front panel.	STUP
14	OUTPUT ON/OFF		Indicates the output status.	p.2-6
15	CV		Illuminates during constant voltage operation.	p.2-13
16	CC		Illuminates during constant current operation.	
17	Voltmeter		Displays the preset output voltage, the output voltage, and the output power.	p.2-2
18	V/W		Voltmeter unit. The LED on the right illuminates when displaying the power.	p.2-2
19	ALM		Illuminates when a protection function is activated.	p.2-15
20	Ammeter		Displays the preset output current, the output current, and the output power.	p.2-2
21	A/W		Ammeter unit. The LED on the right illuminates when displaying the power.	p.2-2

1

2


3

4

5


6

## Rear panel



400 W type example

1600 W type

No.	Name	Description	
1	J1	Connector for external control, series operation, and parallel operation.	p.3-2
2	TP-BUS	Remote control connector	—
3	Serial number	The serial number of the PWR.	—
4	Chassis terminal	A terminal used to ground the output.	STUP
5	Sensing terminal	A terminal used to connect the sensing wires.	p.2-29
6	DC OUTPUT	Output terminal on the rear panel.	STUP
7	Exhaust port	Exhaust port for cooling.	—
8	AC INPUT	400 W and 800 W: AC inlet. 1600 W: AC INPUT terminal block.	STUP






# General Description

This chapter gives firmware version, option, and overview of remote control.

## 1.1 About This Manual

The PWR series is classified into three types depending on the output capacity. It is also classified into three types depending on the output voltage. This operation manual describes the following models.

Table 1-1 PWR series types

	L Type (80 V)	M Type (320 V)	H Type (650 V)
400 W type 	PWR400L	PWR400M	PWR400H
800 W type 	PWR800L	PWR800M	PWR800H
1600 W type 	PWR1600L	PWR1600M	PWR1600H

### Applicable firmware version of the PWR

This manual applies to PWRs with firmware version 1.2x.



Page 2-14

When contacting us about the product, please provide us the version number and the manufacturing number that is affixed to the rear panel.

## 1.2 Options

Below are options available for the PWR series.

For details on the options, contact your Kikusui agent or distributor.

### Rack

Table 1-2 Rack mounting options

Product	Model	Applicable Model	Notes
Rack mount frame	KRA3	400 W type 800 W type	Inch rack EIA standard
	KRA150		Milli rack JIS standard
Rack mount bracket	KRB3-TOS	1600 W type	Inch rack EIA standard
	KRB150-TOS		Milli rack JIS standard





Fig. 1-1 Rack mount frame






Fig. 1-2 Rack mount bracket



## Analog Remote Control Connector Kit(OP01-PAS)

A kit for connecting to the J1 connector on the rear panel.



Component	Quantity
Socket	1 pc.
Pins	10 pcs.
Protection cover	1 set
Chassis connection wire	1 pc.

Fig. 1-3 Analog remote control connector kit

## Handle (for the 400 W type) (CH01-PWR)

A carrying handle that can be attached to the top panel of the 400 W type.




Fig. 1-4 Handle

## 1.3 Rack Mounting the Product

Remove the feet and handle before attaching the product to the rack mount frame. For details on rack mounting, see the operation manual of the KRA series or KRB series.

We recommend that you keep all the parts so that you can use them again when you detach the product from the frame.

To reattach the feet, use the parts that you removed.

### 400 W and 800 W types




Fig. 1-5 Removing the handle and feet (400 W and 800 W types)






Fig. 1-6 Removing the handle and feet (1600 W type)

### Removing the handle and feet

The handle is an option for the 400 W type.

- 1** Pull up on the handle covers (two locations).
- 2** Unfasten the M4 flat head screws (two locations) and remove the entire handle.
- 3** Remove the feet by detaching the screw pins while pulling the feet (four locations) downward.
- 4** Pull the internal pins of the side feet (four locations) using a flat-blade screwdriver and remove the feet (1600 W type only).

---

## 1.4 Remote Control Overview

In addition to operating the PWR from the front panel, you can use a power supply controller (PIA4830/PIA4850/PIA4810) to remotely control the PWR via the USB, GPIB or RS232C interface.

The PWR and power supply controller are connected via a TP-BUS. Up to 32 devices can be connected to the TP-BUS.

For details on the Power Supply Controller, see the operation manual of the respective product. For connection to a Power Supply Controller and device messages, refer to the “Connecting & Programming Guide” in the accompanying CD-ROM.

The latest version of the “Connecting & Programming Guide” can be downloaded from Web site (<http://www.kikusui.co.jp/en/download/>).

---

### NOTE

- Version 2.20 or later is required for the PIA4800 series Power Supply Controller. If you are using an earlier version, you need to update the firmware. For details, contact your Kikusui agent.  
You can check the PIA4800 series version using \*IDN?.
  - The PIA3200 Power Supply Controller is not supported.
-



## Basic Operation

This chapter describes how to turn on/off the output and the basic operations that you can carry out from the front panel.

## 2.1 Measured Value Display and Setting Display

The voltage and current displays have the following three states.

- Measured value display
- Setting display

In addition to the voltage and current displays, OVP/OCP setting, system configuration, and node address displays are available.

### Measured value display

The measured value display shows the present output terminal voltage and load current. In this state, the SET switch LED is off.

See

Page 2-13

You can change the voltage or current while viewing the actual output voltage or output current even with the output turned on.

If you turn the setting knob when the output is off, the SET switch automatically illuminates even if it is off and the setting display appears.




Fig. 2-1 Measured value display example

### ■ Power display

Press the PWR DSPL (SHIFT+CURRENT) switch to display the output power on the ammeter. Press the PWR DSPL (SHIFT+VOLTAGE) switch to display the output power on the voltmeter.

The output power is displayed when the output is on. You can change the voltage or current while viewing the actual output power. The output power is a value calculated from the measured output voltage and measured output current.

The unit (V/w or A/w) to the right of the LED illuminates when the power is displayed. If you press the VOLTAGE or CURRENT switch when the power is displayed, the power display position switches.

Press the PWR DSPL (SHIFT+CURRENT or SHIFT+VOLTAGE) switch to show the measured value display.




Fig. 2-2 Power display example (displaying power on the ammeter)

### Setting display

Press the SET switch. The switch LED illuminates, and the present output voltage or current setting is displayed.

Press the SET switch again to show the measured value display.




Fig. 2-3 Setting display example

## 2.2 Panel control

### For measured value display, setting display, and OVP/OCP setting value display

Turn the setting knob to change the highlighted digit or higher digits on the panel display.

The value can be changed regardless of whether the OUTPUT is on or off.

To set the current to a value greater than 105 % of the rated output current in the extended operating area (L type only), turn the setting knob while holding down the SHIFT switch. You do not have to hold down the SHIFT switch when decreasing the current from a setting greater than or equal to 105 %.

See

Page 2-11




Fig. 2-4 Example of increasing or decreasing the setting

To set the voltage, press the VOLTAGE switch. The voltmeter is highlighted.

To set the current, press the CURRENT switch. The ammeter is highlighted.

If you turn the setting knob when the output is off on the measured value display, the SET switch automatically illuminates even if it is off, and the setting display appears.

## ■ Coarse/Fine

Press the VOLTAGE switch when the voltmeter is highlighted or the CURRENT switch when the ammeter is highlighted to switch between coarse and fine.

You can also press the setting knob to switch between coarse and fine.

The highlighted digit varies depending on the model. See Table 2-1. The underlined digit is highlighted.

Table 2-1 Highlighted digit

Model	Display	Coarse	Fine
PWR400L	Voltmeter/ Ammeter	0 <u>0</u> .00	00.0 <u>0</u>
PWR800L	Voltmeter/ Ammeter	0 <u>0</u> .00	00.0 <u>0</u>
PWR1600L	Voltmeter	0 <u>0</u> .00	00.0 <u>0</u>
	Ammeter	00 <u>0</u> .0	000. <u>0</u>
PWR400M	Voltmeter	00 <u>0</u> .0	000. <u>0</u>
	Ammeter	0. <u>0</u> 00	0.00 <u>0</u>
PWR800M	Voltmeter	00 <u>0</u> .0	000. <u>0</u>
	Ammeter	00. <u>0</u> 0	00.0 <u>0</u>
PWR1600M	Voltmeter	00 <u>0</u> .0	000. <u>0</u>
	Ammeter	00. <u>0</u> 0	00.0 <u>0</u>
PWR400H	Voltmeter	0 <u>0</u> 0.0	000. <u>0</u>
	Ammeter	0. <u>0</u> 00	0.00 <u>0</u>
PWR800H	Voltmeter	0 <u>0</u> 0.0	000. <u>0</u>
	Ammeter	0. <u>0</u> 00	0.00 <u>0</u>
PWR1600H	Voltmeter	0 <u>0</u> 0.0	000. <u>0</u>
	Ammeter	0 <u>0</u> .00	00.0 <u>0</u>

## ■ For other displays

When showing the system configuration display, use the setting knob to change the highlighted setting.

## 2.3 Output Operation

The OUTPUT switch is a toggle switch. When the output is on, the OUTPUT ON indicator on the display illuminates; when the output is off, the OUTPUT OFF indicator illuminates.

When the output is on, the present setting is output. If you change the setting while the output is on, the change is applied to the output.




Fig. 2-5 Output indication

### Output on/off when power is turned on

By factory default, the output is off when the power is turned on. You can set the output state at power-on to on (C-4: 1) in the CONFIG settings.

If you set the output state at power-on to on, check the OVP trip point setting before you turn off the POWER switch.

If the breaker trip setting that is applied when a protection function activates is set to “trip” (C-8: 0) and the OVP trip point is set lower than the output voltage setting, the OVP will activate every time you turn the POWER switch on and the POWER switch will turn off.

If the condition above occurs and you are unable to change any of the settings, turn the POWER switch on while holding down the OUTPUT switch to power up with the output temporarily turned off.

- 
- CAUTION** • If the OVP/OCP settings are not appropriate when you change the load, the load may break.
-



## 2.4 Description of Operation

The PWR is a constant voltage/current regulated DC power supply that is capable of delivering voltages and currents in a wide operating range within the rated output power. Fig. 2-6 shows the operating area of the 400 W type.

See

Page 2-11

[A] in the figure indicates the rated operating area, and [B] indicates the extended operating area. The extended operating area is valid only on the L type.

If the PWR is configured in way that satisfies the equation  $\text{output voltage} \times \text{output current} \leq \text{rated output power}$ , the PWR operates as a conventional constant voltage/current power supply.

See

Page 2-22

If the PWR is configured in a way that satisfies the equation  $\text{output voltage} \times \text{output current} > \text{rated output power}$ , the actual output is limited by the power limit (approx. 105% of the rated output power) and the output voltage or output current varies depending on the load value.




Fig. 2-6 Operating area (400 W type example)

The output current must be derated with respect to the temperature at ambient temperatures greater than or equal to 45 °C (30 °C when operating in the extended operating area) on the L type and 40 °C on the M/H type.




Fig. 2-7 Derating of the output current

## 2.4.1 Constant Voltage (CV) and Constant Current (CC) Power Supplies

The PWR has a constant voltage power supply function that maintains the output voltage at a constant level and a constant current power supply function that maintains the output current at a constant level even when the load changes. The condition in which the PWR is operating as a constant voltage power supply is called the constant voltage (CV) mode. The condition in which the PWR is operating as a constant current power supply is called the constant current (CC) mode. The operation mode is determined by the following three values.

- Preset output voltage ( $V_s$ )
- Preset output current ( $I_s$ )
- Load resistance ( $R_L$ )

The operation modes are described below.




Fig. 2-8 Constant voltage operation and constant current operation

Fig. 2-8 shows the operation modes of the PWR. We denote the load resistance as  $R_L$  and the resistance calculated from the preset current and voltage as  $R_c$  ( $R_c = V_s/I_s$ ). The power supply is designed so that it operates in CV mode in area  $\square A$  and CC mode in area  $\square B$ . The boundary is the line defined by  $R_L = R_c$ . This line represents the load at which the output voltage and the preset voltage are equal and the output current and preset current are equal. If load resistance  $R_L$  is greater than resistance  $R_c$ , the operating point is in area  $\square A$ , and the PWR operates in CV mode (point p). In this case, preset current  $I_s$  is the current limit.

When operating in CV mode, the output voltage is maintained at the preset voltage. Output current  $I$  is determined by the relationship defined by the equation  $I = V_s/R_L$ . It is a current less than current limit  $I_s$ . In this mode, the actual current that flows is not necessarily equal to the specified value.

For loads in which transient peak current flows, preset current  $I_s$  must be set so that the peak value does not reach the current limit.

Conversely, if load resistance  $R_L$  is less than resistance  $R_c$ , the operating point is in area  $\square B$ , and the PWR operates in CC mode (point q). In this case, preset voltage  $V_s$  is the voltage limit.

When operating in CC mode, the output current is maintained at the preset current. Output voltage  $V$  is determined by the relationship defined by the equation  $V = I_s \times R_L$ . It is a voltage less than voltage limit  $V_s$ . In this mode, the actual voltage that is applied is not necessarily equal to the specified value.

---

For loads that generate transient surge voltage, preset voltage  $V_s$  must be set so that the surge voltage does not reach the voltage limit.

### ■ Crossover point

CV mode and CC mode switch automatically according to the changes in the load. The point at which the mode switches is called the crossover point.

For example, if the load changes and the output current reaches the current limit when operating in CV mode, the operation mode automatically switches to CC to protect the load. Likewise, if the output voltage reaches the voltage limit when operating in CC mode, the operation mode automatically switches to CV.

### CV and CC mode operation example

This section uses a power supply with a rated output voltage of 100 V and a rated output current of 10 A as an example.

A load resistance ( $R_L$ ) of 8  $\Omega$  is connected to the output terminals of the power supply. The output voltage and output current are set to 30 V and 5 A, respectively. In this case,  $R_c = 30 \text{ V} / 5 \text{ A} = 6 \Omega$ . Since, 8  $\Omega$  is greater than 6  $\Omega$  ( $R_L > R_c$ ), the operation mode is CV. If you want to increase the voltage in CV mode, the voltage can be increased up to the voltage defined by the following equation:  $V_s = I_s \times R_L$ . Substituting the values, we obtain  $V_s = 5 \text{ A} \times 8 \Omega = 40 \text{ V}$ . If you try to increase the voltage above this point, the crossover point is reached, and the operation mode automatically switches to CC mode. To maintain CV mode, increase the current limit.

Next a load resistance ( $R_L$ ) of 5  $\Omega$  is connected to the output terminals of the power supply. The output voltage and output current are set to 30 V and 5 A, respectively. In this case,  $R_c = 30 \text{ V} / 5 \text{ A} = 6 \Omega$ . Since, 5  $\Omega$  is greater than 6  $\Omega$  ( $R_L < R_c$ ), the operation mode is CC. If you want to increase the current in CC mode, the current can be increased up to the current defined by the following equation:  $I_s = V_s / R_L$ . Substituting the values, we obtain  $I_s = 30 \text{ V} / 5 \Omega = 6 \text{ A}$ . If you try to increase the current above this point, the crossover point is reached, and the operation mode automatically switches to CV mode. To maintain CC mode, increase the voltage limit.



## 2.4.2 Extended operating area (L type only)

Of the output current setting range of the PWR as illustrated in Fig. 2-9, the range between the rated output current and the maximum output current (160 % of the rating) is the extended operating area.




Fig. 2-9 Extended operating area



Fig. 2-10

The specifications of load fluctuation, input fluctuation, ripple/noise, and so on are not met in the extended operating area. The extended operating area is divided into the continuous extended operating area and the intermittent extended operating area with the limitations listed below.

- Continuous output is possible in the continuous extended operating area. However, at ambient temperatures greater than or equal to 30 °C, the output current must be derated with respect to the temperature.
- The output duration is limited in the intermittent extended operating area. See Table 2-2.

When using the PWR in the extended operating area, pay attention to the ambient temperature, preset current, and output duration.

The ALM LED blinks when operating in the extended operating area. In this case, the ALM signal is not output.




Fig. 2-10 Derating of the output current (L type)

Table 2-2 Guideline of the time duration of operation in the intermittent extended operating area

Maximum Output Duration <sup>*1</sup>	Pause Duration <sup>*1</sup>
10 minutes	At least twice the output duration

\*1. When operating by itself with no devices that generate heat around the PWR.

**NOTE**

- If you attempt to output a current exceeding the conditions of use as described above, the internal protection function trips, and the OUTPUT is turned off.
- When rack mounting multiple PWRs, pay attention to the ambient temperature and the output current derating.

## 2.5 Using the PWR as a CV or CC Power Supply (Setting the Output Voltage and Current)

When using the PWR as a constant voltage power supply, the preset current is the limit that can flow through the load.

When using the PWR as a constant current power supply, the preset voltage is the limit that can be applied to the load.

If the specified limit is reached, the operation mode automatically switches. If the operation mode switches, the CV and CC indicators on the display change to indicate the switch.

- 1 Turn the POWER switch off.
- 2 Connect the load to the output terminal.
- 3 Turn the POWER switch on.

If the OUTPUT ON indicator on the display is illuminated, press the OUTPUT switch to turn the output off.

- 4 Press the SET switch to show the setting display.

The SET switch illuminates.

- 5 Use the VOLTAGE switch and setting knob to set the voltage.

- 6 Use the CURRENT switch and setting knob to set the current.

- 7 Press the OUTPUT switch to turn the output on.

The SET switch turns off, and the OUTPUT ON indicator on the display illuminates. Voltage/current is delivered to the output terminal. The CV indicator on the display illuminates when the PWR is operating as a constant voltage power supply. The CC indicator illuminates when the PWR is operating as a constant current power supply.



Page 2-4

---

You can change the actual output voltage or output current while viewing the value even with the output turned on by carrying out step 5 and step 6 .



Page 2-2

You can also change the actual output voltage or output current while viewing the power.

The internal capacitor is charged when the output is turned on. Depending on the preset current, the PWR may instantaneously enter CC mode.





## 2.6 Protection Function and Alarm

The PWR is equipped with the following protection function.

- Overvoltage protection (OVP)
- Overcurrent protection (OCP)
- Overpower protection (OPP)
- Overheat protection (OHP)
- Shutdown (SHUT)
- Power limit (POWER LIMIT)

### 2.6.1 Alarm occurrence and release

#### Alarm occurrence

When a protection function activates, the PWR behaves as follows:




Fig. 2-11 Alarm indication (OHP example)

- Output off (excluding the case when the power limit trips).  
For the overvoltage protection (OVP), overcurrent protection (OCP), overpower protection (OPP), and shutdown (SHUT), you can select breaker trip in the CONFIG settings.
- The ALM indicator on the front panel display illuminates or blinks. The ALM indicator illuminates approximately 0.5 to 3 seconds even if the breaker trips.
- The alarm signal is output from pin 20 of the J1 connector (excluding the case when the power limit trips).  
The alarm signal is delivered approximately 0.5 to 3 seconds even if the breaker trips.

The ALM LED blinks when operating in the extended operating area. In this case, the ALM signal is not output.



Page 2-27

## ■ Breaker trip function when the OVP, OCP, OPP, or SHUT is activated



Page 2-27

You can select whether to trip the breaker (C-8: 0/1) when the OVP, OCP, or OPP function activates or when a shutdown signal is applied.

The breaker trip function is common to OVP, OCP, OPP, and SHUT. It cannot be set separately by protection function.

## Clearing the alarm

If you cannot clear the alarm even when all of the causes of the alarm are eliminated, the PWR may have malfunctioned. If this happens, stop using the PWR and contact your Kikusui agent or distributor.

## ■ When the breaker trips (when the POWER switch turns off)

After eliminating the cause of the alarm, turn on the POWER switch.

## ■ When the output turns off

Turn off the POWER switch, eliminate the cause the alarm, and then turn the POWER switch back on.

## Alarm signal

The alarm signal output is isolated from other terminals by an open-collector photocoupler.

Maximum voltage: 30 V

Maximum current: 8 mA




Fig. 2-12 Alarm signal

## 2.6.2 Overvoltage protection (OVP) and overcurrent protection (OCP)

The overvoltage protection (OVP) and overcurrent protection (OCP) functions activate under the following conditions.

Conditions in which the OVP is activated

- When the output terminal voltage exceeds the specified voltage (OVP trip point).
- When the sensing cable comes loose.
- When there is a problem with the load or the PWR.

Conditions in which the OCP is activated

- When the output current exceeds the specified current (OCP trip point).
- When there is a problem with the load or the PWR.

You must set appropriate values for the OVP and OCP trip points. Be sure to first set the OVP and OCP trip points appropriate for the load immediately after installing the PWR or changing the load.

You can select whether to trip the breaker (C-8: 0/1) when the OVP or OCP function activates.



Page 2-27

### Setting the trip points

You can set the trip points regardless of whether the output is on or off.

The OVP function of the PWR operates against the output terminal voltage. If you want to activate the function on the voltage across the load, set the OVP trip point by considering the voltage drop in the load wire.

Table 2-3 OVP trip point range

Type	OVP Trip Point Range
L type	8.0 V to 88.0 V
M type	32.0 V to 352.0 V
H type	65.0 V to 715.0 V

Table 2-4 OCP trip point range

Model	OCP Trip Point Range	Model	OCP Trip Point Range
PWR400L	2.50 A to 44.00 A	PWR400M	0.625 A to 6.875 A
PWR800L	5.00 A to 88.00 A	PWR800M	1.25 A to 13.75 A
PWR1600L	10.00 A to 176.0 A	PWR1600M	2.50 A to 27.50 A
PWR400H	0.20 A to 2.20 A		
PWR800H	0.40 A to 4.40 A		
PWR1600H	0.80 A to 8.80 A		




Fig. 2-13 OVP/OCP setting value display example

## ■ Setting the OVP trip point

### 1 Press the OVP switch.

The voltmeter shows the setting, and the ammeter shows “OVP.”

### 2 Use the VOLTAGE switch and setting knob to set the OVP trip point.

If the output is on and the OVP trip point is set lower than the preset output voltage, the OVP trips, and the output turns off or the POWER switch turns off.

### 3 Press the OVP switch to exit from the OVP setup.

The measured value display appears.

See

Page 2-4

## ■ Setting the OCP trip point

**1** Press the OCP (SHIFT+OVP) switch.  
The ammeter shows the setting, and the voltmeter shows “OCP?”



Page 2-4

**2** Use the CURRENT switch and setting knob to set the OCP trip point.

If the output is on and the OCP trip point is set lower than the preset output current, the OCP trips, and the output turns off or the POWER switch turns off.

**3** Press the OCP (SHIFT+OVP) switch to exit from the OCP setup.

The measured value display appears.

## Checking the OVP or OCP operation

The OVP or OCP is a function for protecting the load. Once you set the OVP or OCP trip point, check that the OVP or OCP works before you connect the load by carrying out the procedure below.



Page 2-26

**1** Check that the output status setting at power-on is set to “output off at power-on” (C-4: 0).

**2** Check that the load is not connected to the output terminal.

If it is, turn the POWER switch off and disconnect the load. Then, turn the POWER switch on.

**3** Press the OUTPUT switch to turn the output off.

The OUTPUT OFF indicator on the display illuminates.



Page 2-4

**4** Set the output voltage to a value less than the OVP-trip point.

**5** Press the OUTPUT switch to turn the output on.

The OUTPUT ON indicator on the display illuminates.

- 
- 6** Turn the setting knob slowly clockwise, and check that the output turns off or the breaker trips when the output voltage exceeds the preset OVP trip point.
  - 7** Turn the POWER switch off.
  - 8** Short the output terminal.
  - 9** Turn the POWER switch on.
  - 10** Set the output voltage to a value less than the OVP trip point.
  - 11** Set the output current to a value less than the OCP trip point.
  - 12** Press the OUTPUT switch to turn the output on.  
The OUTPUT ON indicator on the display illuminates.
  - 13** Turn the setting knob slowly clockwise, and check that the output turns off or the breaker trips when the output current exceeds the preset OCP trip point.
  - 14** Set the output current to a value less than the OCP trip point.



## 2.6.3 Other Protection Functions

### Overpower protection (OPP)

This function is activated when a condition that exceeds approximately 110 % of the rated output power persists for a certain period (approximately 2 seconds) such as due to a transient load change.

You can select whether to trip the breaker (C-8: 0/1) when the OPP function activates.



Page 2-27

Table 2-5 OPP value (fixed)

Type	OPP Value
400 W type	440 W
800 W type	880 W
1600 W type	1760 W

### Overheat protection (OHP)

This function protects the PWR with turning off the output when the internal temperature rises abnormally.

The OHP is activated under the following conditions.

- When the PWR is operated outside its operating temperature range (0 °C to +50 °C).
- When the PWR is used with the intake or exhaust port blocked.
- When the fan motor stops.

If you turn the POWER switch back on without correcting the condition that caused the OHP, the OHP will be activated again.

---

## Shutdown (SHUT)



Page 3-21

Shutdown is not activated as a result of the PWR detecting an error. It is a function used to turn off the output by applying an external signal to the J1 connector on the rear panel when an abnormal condition occurs.



Page 2-27

You can select whether to trip the breaker (C-8: 0/1) when the shutdown signal is applied..

## Power limit (PL:POWER LIMIT)

This function varies the output voltage or output current according to the changes in the load resistance. It limits the output power at approximately 105 % of the rated output power and does not turn the output off.

The ALM indicator blinks while the power limit is activated. In this case, the alarm signal is not output.

Table 2-6 Power limit value (fixed)

Type	Power Limit Value
400 W type	420 W
800 W type	840 W
1600 W type	1680 W





## 2.7 CONFIG Settings

CONFIG settings are used to set the system configuration of the PWR. You can set or display the parameters in Table 2-7 in the CONFIG settings.




Fig. 2-14 CONFIG setting/display example

- **Parameter number**  
Displays the parameter number on the voltmeter.
- **Preset number**  
Displays the CONFIG parameter setting as a value with the lowest 2 digits of the ammeter.

Table 2-7 CONFIG parameter number and setting

Parameter Number	CONFIG Parameter
C-1	CV control source setting.
C-2	CC control source setting.
C-3	Remote sensing setting.
C-4	Output status setting at power-on.
C-5	Serial/parallel master-slave operation setting.
C-6	External control logic setting of the output on/off.
C-7	Termination setting during remote control
C-8	Breaker trip setting when the protection function trips.
C-9	Status signal setting of the power on/off.

---

## Setting the system configuration

Set the system configuration of the PWR.

- 1** While holding down the CONFIG switch, turn on the POWER switch.  
Keep holding down the CONFIG switch until the voltmeter displays “ConF.”  
The CONFIG switch illuminates, and a parameter number highlighted.
- 2** Turn the setting knob to select the parameter number you want to set.
- 3** Press the CURRENT switch to select the preset number.  
The preset number is highlighted.
- 4** Turn the setting knob to select the preset number you want to set.
- 5** To continue setting the system configuration, press the VOLTAGE switch to select the CONFIG parameter number. Then, repeat steps step 2 to step 4 .
- 6** When you are done, turn off the POWER switch.  
The specified operating conditions are stored by the PWR when the POWER switch is turned off.

## Checking the system configuration

Check the system configuration of the PWR.

- 1** Press the CONFIG switch when the POWER switch is turned on.  
The CONFIG switch illuminates..
- 2** Turn the setting knob to select the parameter number, and check the preset number.  
The setting corresponding to the parameter number is displayed with the lowest 2 digits on the ammeter. The CURRENT switch is invalid.
- 3** Press the CONFIG switch to end the CONFIG display.  
The CONFIG switch turns off, and the measured value display appears.

## CONFIG parameter details

The details of the CONFIG parameters are described below.

### C-1 CV control source setting

Selects the constant voltage control mode.

See

Page 3-10  
Page 3-12

Preset Number	Description
0	Panel control (Factory default)
1	External voltage control
2	External resistance control 10 k $\Omega$ $\rightarrow$ MAX OUT
3	External resistance control 10 k $\Omega$ $\rightarrow$ 0 OUT (FAIL SAFE)

### C-2 CC control source setting

Selects the constant current control mode.

See

Page 3-16

Preset Number	Description
0	Panel control (Factory default)
1	External voltage control
2	External resistance control 10 k $\Omega$ $\rightarrow$ MAX OUT
3	External resistance control 10 k $\Omega$ $\rightarrow$ 0 OUT (FAIL SAFE)

### C-3 Remote sensing setting

Selects whether to perform remote sensing.

See

Page 2-29

Preset Number	Description
0	Disable remote sensing. (Factory default)
1	Enable remote sensing.

## C-4 Output status setting at power-on



Page 2-29

Sets the output state when the POWER switch is turned on. This setting is invalid when the output is turned off using an external contact.

Preset Number	Description
0	Output is off at power-on. (Factory default)
1	Output is on at power-on.

## C-5 Serial/parallel master-slave operation setting



Page 4-6  
Page 4-14

Sets the PWR condition during master-slave series/parallel operation. Select 0 for independent operation.

Preset Number	Description
0	Master unit or independent operation. (Factory default)
1	Slave unit during parallel operation.
2	Slave unit during series operation (L type only).

## C-6 External control logic setting of the output on/off



Page 3-18

Sets the logic used to control the output on/off using an external contact (J1 connector).

Select 0 when not controlling the output on/off with an external contact.

Preset Number	Description
0	Turn the output on with a high signal. (Factory default)
1	Turn the output on with a low signal.



## C-7 Termination setting during remote control

Turns on/off the termination for remote control.

Preset Number	Description
0	Termination: Off (Factory default)
1	Termination: On

## C-8 Breaker trip setting when the protection function trips



Page 3-21

Sets whether to trip the breaker (turn the POWER switch off) when the OVP (overvoltage protection), OCP (overcurrent protection), OPP (overpower protection) is activated or when an external shutdown (SHUT) signal is applied.

Preset Number	Description
0	Trip (turn the POWER switch off). (Factory default)
1	Not trip (turn the output off).

## C-9 Status signal setting of the power on/off



Page 3-23

Sets whether to output a low level signal when the power is on or when the power is off when monitoring the PWR power on/off status externally (through the J1 connector).

Preset Number	Description
0	Output a low level signal while the power is on (PWR ON STATUS). (Factory default)
1	Output a low level signal for 0.5 s to 3 s when the power is off (PWR OFF STATUS).

---

## 2.8 Lock Function

The PWR has a lock function that prevents the settings from being changed inadvertently.

When the panel lock is enabled (LOCK switch illuminates), the switches on the front panel (excluding the OUTPUT switch) and the setting knob are disabled.

**1** Set all the required parameters such as the output voltage and output current.

**2** Press the LOCK switch.

The LOCK switch illuminates, and panel lock is enabled.

Press the LOCK switch again to release the panel lock.



## 2.9 Remote Sensing Function

The remote sensing function is used to reduce the influence of voltage drops due to the load wire resistance and stabilize the output voltage across the load.

The remote sensing function of the PWR can compensate up to approximately 0.6 V for a single line. Select a load wire with sufficient current capacity so that the voltage drop in the load wire does not exceed the compensation voltage.

To perform remote sensing, an electrolytic capacitor may be required at the sensing point (load terminal).

### Connecting the sensing cable



**WARNING**

**Possible electric shock or damage to the internal circuitry.**

- **Never wire the cable to the sensing terminals while the POWER switch is turned on.**
- **Use sensing wires with a higher voltage rating than the isolation voltage of the PWR. Protect the uncovered section of the shielded wire by using insulation tubes with a withstand voltage greater than the isolation voltage of the PWR. For the isolation voltage of each model, “see Chapter 6 “Specifications.”**
- **To turn on/off the power supplied to a load using a mechanical switch, provide additional switches between the sensing cables as shown in Fig. 2-16 and turn on/off the power and remote sensing cables simultaneously. Be sure to turn off the OUTPUT switch or POWER switch before turning on/off the mechanical switch.**

If the sensing cables come loose, the output voltage across the load cannot be stabilized and may cause excessive voltage to be applied to the load. If an appropriate OVP trip point is set, the OVP trips and prevents excessive voltage output.

After you are done using the remote sensing function, remove the sensing wires, and be sure to turn off remote sensing in the CONFIG settings (C-3: 0).




Fig. 2-15 Remote sensing connection

- 1 Turn on remote sensing through CONFIG settings (C-3: 1).
- 2 Turn the POWER switch off.
- 3 As shown in Fig. 2-15, connect the sensing cable between the sensing terminal and the load terminal.

To decrease output ripple voltages resulting from inductive effects, use a two-core shielded wire for the sensing cables. Connect the shield to the - (neg.) terminal.

If you cannot use shielded wires, twist the + (pos.) and - (neg.) wires thoroughly.



### ■ Electrolytic capacitor connected at the load end

If the inductance in the wire is large, the following symptoms may appear.

- Oscillation

If the wiring cable to a load is long, the phase shift caused by the inductance and capacitance of the wiring becomes non-negligible, thereby causing oscillation.

- Fluctuating output

If the load current changes suddenly to pulse form, the output voltage may increase due to the effects from the inductance component of the wiring.

Twisting the load wires reduces the inductance, thereby stabilizing the output. However, if this does not solve the problem, connect an electrolytic capacitor at the load end.

Electrolytic capacitor required

Capacitance: 0.1  $\mu\text{F}$  to several hundred  $\mu\text{F}$

Withstand voltage: Greater than or equal to 120 % of the rated output voltage of the PWR

### ■ When inserting a mechanical switch between the PWR and the load

If you are using a mechanical switch that is inserted between the PWR and the load to turn on/off the connection between them, insert a switch also in the sensing cable as shown in Fig. 2-16 and turn on/off the load wire and the sensing cable simultaneously. Be sure to turn off the OUTPUT switch or POWER switch before turning on/off the mechanical switch.




Fig. 2-16 On/off using the mechanical switch

## 2.10 Factory Default Settings

Turning ON the POWER switch while holding down the SHIFT switch initializes the settings to factory default (excluding the node address setting).

If you want to reset all the settings to factory default, set the node address to 5 after carrying out the initialization procedure above.


The factory default settings are given in the tables below.

Table 2-8 Basic settings

Basic item	Setting
Output voltage	0 V
Output current	105 % of the rated output current
OVP (overvoltage protection)	110 % of the rated output voltage
OCP (overcurrent protection)	176 % of the rated output current (L type) 110 % of the rated output current (M/H type)

Table 2-9 CONFIG settings (values are all zeroes)

Parameter number	CONFIG parameter	Setting
C-1	CV control source	Panel control
C-2	CC control source	Panel control
C-3	Remote sensing	Disable
C-4	Output status setting at power-on	Output is off at power-on.
C-5	Serial/parallel master-slave operation	Master unit or independent operation.
C-6	External control logic setting of the output on/off	Turn the output on with a high signal.
C-7	Termination during remote control	Off
C-8	Breaker trip when the protection circuit is activated	Trip
C-9	Status signal of the power on/off	Output a low level signal while the power is on.



## External Control

This chapter describes external control and external monitoring using the J1 connector.

---

## 3.1 Overview of External Control

The J1 connector on the rear panel of the PWR can be used to perform external control listed below.

- Output voltage control  
Control using external voltage or external resistance
- Output current control  
Control using external voltage or external resistance
- Output on/off using external contact
- Shutdown using external contact

## 3.2 J1 connector

At the factory shipment, the protection socket is attached to the J1 connector. Keep this protection socket and be sure to attach when the J1 connector is not used. If the protection socket is damaged or lost, contact Kikusui distributor/agent.




Fig. 3-1 Protection socket



### **WARNING** Possible electric shock.

- **The J1 connector contains pins that are at the same electric potential as the output terminal. If you are not using the J1 connector, be sure to insert the protective socket provided.**
- **Be sure to use the protective cover on the sockets.**

---

The connector parts needed to connect the J1 connector (standard MIL connector) are not provided. Table 3-1 shows the tools and parts that are needed.

For information on how to obtain the tools and parts, contact your Kikusui agent or distributor.

An optional OP01-PAS Analog Remote Control Connector Kit is available for making the connection.




Fig. 3-2 OP01-PAS [84500]

Table 3-1 Connector parts by Omron needed to connect the J1 connector

Product	Model	Kikusui Parts No.	Notes
Single contact connection tool	XY2B-7006	Y2-070-001	–
Contact removal tool	XY2E-0001	Y2-070-002	–
Pin (contact)	XG5W-0031	84-49-0100	Recommended wire size AWG24 (UL-1061)
Socket	XG5M-2632-N	84-49-0160	MIL standard type socket
Protection cover (semi cover)	XG5S-1301	84-49-0161	–

For details on how to use the tools, read the catalog by Omron.

### J1 connector arrangement




Fig. 3-3 J1 connector

Table 3-2 J1 connector arrangement

Pin No.	Signal Name	Description
1	A COM	An analog signal common for pins 3 to 7. Connected to the negative electrode (-S) of the sensing input when remote sensing is used; connected to - (neg.) output when remote sensing is not used.
2	D COM	Connected to the negative electrode (-S) of the sensing input when remote sensing is used; connected to - (neg.) output when remote sensing is not used.
3	OUT ON/OFF CONT	Output on/off terminal. Turns off when a low (or high) TTL level signal is applied. The internal circuit is pulled up to +5 V through 10 k $\Omega$ .
4	EXT V CV CONT	External voltage control of the output voltage. (0 % to 100 % of the rated output voltage in the range of 0 V to 10 V).
5	EXT V CC CONT	External voltage control of the output current. (0 % to 100 % of the maximum output current in the range of 0 V to 10 V).
6	EXT R CV CONT	External resistance control of the output voltage. 0 % to 100 % of the rated output voltage in the range of 0 k $\Omega$ to 10 k $\Omega$ or 100 % to 0 % of the rated output voltage in the range of 0 k $\Omega$ to 10 k $\Omega$ .
7	EXT R CC CONT	External resistance control of the output current. 0 % to 100 % of the rated output current in the range of 0 k $\Omega$ to 10 k $\Omega$ or 100 % to 0 % of the rated output current in the range of 0 k $\Omega$ to 10 k $\Omega$ . <sup>*1</sup>
8	V MON	Output voltage monitor (outputs 0 % to 100 % of the rated voltage using 0 V to 10 V).
9	I MON	Output current monitor (outputs 0 % to 100 % of the maximum current using 0 V to 10 V).
10	SHUT DOWN	Shutdown (Turns the output or POWER switch off when a low TTL level signal is applied. The internal circuit is pulled up to +5 V through 10 k $\Omega$ ).
11	SER IN+	Positive electrode input terminal during master-slave series operation.
12	PRL IN+	Positive electrode input terminal during master-slave parallel operation.
13	S/P IN-	Negative electrode input terminal during master-slave series/parallel operation.



Pin No.	Signal Name	Description
14	COMP IN	Correction signal input terminal during master-slave parallel operation
15	NEXT PRL OUT+	Positive electrode output terminal to the next device during master-slave parallel operation.
16	NEXT COMP OUT	Correction signal output terminal to the next device during master-slave parallel operation.
17	STATUS COM	Common for status signals from pin 18 through 22.
18	CV STATUS	Turns on during CV operation (open collector output by a photocoupler). <sup>*2</sup>
19	CC STATUS	Turns on during CC operation (open collector output by a photocoupler). <sup>*2</sup>
20	ALM STATUS	Turns on when the OVP, OCP, OPP, or OHP trips or when a shutdown signal is applied (open collector output by a photocoupler) <sup>*2</sup>
21	OUT ON STATUS	Turns on when the output is on (open collector output by a photocoupler) <sup>*2</sup>
22	PWR ON/OFF STATUS	PWR ON STATUS (C-9:0):Outputs a low level signal when the power is on. PWR OFF STATUS (C-9:1):Output a low level signal for approximately 0.5 to 3 s when the power is turned off. (open collector output by a photocoupler) <sup>*2, *3</sup>
23	SER OUT+	Positive electrode output terminal during master-slave series operation.
24	PRL OUT+	Positive electrode output terminal during master-slave parallel operation.
25	S/P OUT-	Negative electrode output terminal during master-slave series/parallel operation
26	COMP OUT	Correction signal output terminal during master-slave parallel operation.

\*1. The maximum current is the rated current on the M/H type.

\*2. Open collector output:Maximum voltage of 30 V and maximum current of 8 mA.

It is insulated from the control circuit.

\*3. PWR ON/OFF STATUS: Either PWR ON STATUS (C-9: 0) or PWR OFF STATUS (C-9:1) that you specify using the status signal setting of the output on/off is activated.

---

## 3.3 Output Terminal Insulation

Note the following points and insulate the output terminals.

---

**⚠ WARNING**

- **Possible electric shock. For safety reasons, even if the output terminal is grounded, make sure the insulation capacity of the output terminal (including the sensing terminal) is greater than the isolation voltage of the PWR. For the isolation voltage of each model, see Chapter 6 “Specifications.”**

**If you cannot obtain a wire with sufficient rated voltage, secure adequate withstand voltage by passing the wire through an insulation tube with a withstand voltage greater than the isolation voltage of the PWR.**

**⚠ CAUTION**

- The signal wire may burn out. If the PWR is to be controlled through an external voltage (Vext), do not ground it (leave it floating).

---

The wire and load that are connected to the output terminal (including the sensor terminal) must have an insulation capacity that is greater than the isolation voltage of the PWR with respect to the chassis. Isolation voltage indicates the maximum allowed voltage that appears across the output terminal of the power supply unit and the protective conductor terminal (chassis terminal).



### 3.3.1 When the Output Terminal Is Not Grounded (Floating)

The output terminal of the PWR is isolated from the protective conductor terminal. By connecting the GND wire of the power cord to the ground terminal of the switchboard, the chassis of the PWR is set to ground potential as shown in Fig. 3-4.

Pins 3 through 16 of the J1 connector on the rear panel (for external control and output monitoring) are at approximately the same potential as the - (neg.) output terminal of the PWR. Therefore, wires and devices that are connected to these pins must also have an insulation capacity that is greater than the isolation voltage of the PWR.




Fig. 3-4 When the output terminal is not grounded

### 3.3.2 When the Output Terminal Is Grounded

If the positive output terminal is connected to the chassis terminal, the terminal is at ground potential as shown in Fig. 3-5. Therefore, the wires and load that are connected to the output terminal (including the sensing terminal) only require an insulation capacity that is greater than the maximum output voltage of the PWR with respect to the chassis.

The same holds true when the negative terminal is connected to the chassis terminal. The wire and load require an insulation capacity that is greater than the maximum output voltage of the PWR.

For safety reasons, connect either output terminal to the chassis terminal unless your application requires the output terminal to be floating.




Fig. 3-5 When the + (pos.) output terminal is grounded

## Precautions to be taken when using the external voltage (Vext)

Be sure that the output is not shorted as shown in Fig. 3-6 and Fig. 3-7.

**CAUTION** The signal wire may burn out.

- Leave the Vext output floating.
- If you are connecting the shield at the Vext end, do not connect the shield to the output terminal of the PWR.




Fig. 3-6 The output is short-circuited by the grounding of Vext (example of a prohibited connection)




Fig. 3-7 The output is short-circuited by the shield (example of a prohibited connection)

---

## 3.4 Output Voltage Control

This section explains the method used to control the output voltage using an external voltage ( $V_{ext}$ ) in the range 0 V to approx. 10 V or an external resistor ( $R_{ext}$ ) in the range 0 k $\Omega$  to approx. 10 k $\Omega$ .

If no load is connected, it takes a long time for the output voltage to fall.



**WARNING** Possible electric shock.

- **The insulation of the  $V_{ext}$  or  $R_{ext}$  and the connected wire should be greater than the isolation voltage of the PWR. For the isolation voltage of each model, see Chapter 6 “Specifications.”**
  - **When using shielded wires for the connection, protect the uncovered section of the shielded wire by using insulation tubes with a withstand voltage greater than the isolation voltage of the PWR.**
- 

### 3.4.1 External Voltage ( $V_{ext}$ ) Control



Page 2-23

To control the output voltage using  $V_{ext}$ , set the CV control source in the CONFIG settings to external voltage control (C-1: 1).

The output voltage ( $E_o$ ) varies in the range of 0 to the rated output voltage ( $E_{rtg}$ ) by setting the external voltage ( $V_{ext}$ ) in the range of 0 V to 10 V.

$$E_o = E_{rtg} \times V_{ext} / 10 \text{ [V]} \quad V_{ext} = 10 \times E_o / E_{rtg} \text{ [V]}$$



**CAUTION**

- The signal wire may burn out. Leave the  $V_{ext}$  output floating.
  - If the polarity is reversed, the PWR may break. Make sure the polarity of  $V_{ext}$  is correct.
  - The PWR may break. Do not apply voltage or reverse voltage exceeding 10.5 V across the external voltage control pins.
- 



## Connecting the external voltage (Vext)

Use a low-noise and stable voltage source for Vext. The noise in Vext is multiplied by the amplification factor of the PWR and appears at the output. Thus, the output ripple noise may not meet the PWR's specifications.

To minimize the influence of noise on the output, use a two-core shielded wire or a twisted-pair wire to connect the control terminals and Vext. Make the wires as short as possible. Susceptibility to the effects of noise increases as the wires get longer. When wires are long, proper operation may be hindered even if a cable with anti-noise measures is used.

When using a shielded cable, connect the shield to the - (neg.) output terminal. If the shield needs to be connected to the Vext end, see "Precautions to be taken when using the external voltage (Vext)."

Pins 1 and 4 of the J1 connector are used. The input impedance across the pins is approximately  $30\text{ k}\Omega$ .

See  
Page 3-9




Fig. 3-8 Connection of the output voltage control using Vext

---

## 3.4.2 External Resistance (Rext) Control

See

Page 2-23

To control the output voltage using Rext, select the CV control source in the CONFIG settings from the following two modes.

- External resistance control 10 kΩ → MAX OUT (C-1: 2)

The output voltage (Eo) varies in the range of 0 to the rated output voltage (Ertg) by setting the external resistance (Rext) in the range of 0 kΩ to 10 kΩ.

$$E_o = E_{rtg} \times R_{ext} / 10 \text{ [V]} \quad R_{ext} = 10 \times E_o / E_{rtg} \text{ [V]}$$

- External resistance control 10 kΩ → 0 OUT (FAIL SAFE) (C-1: 3)

The output voltage (Eo) varies in the range of the rated output voltage (Ertg) to 0 by setting the external resistance (Rext) in the range of 0 kΩ to 10 kΩ.

$$E_o = E_{rtg} \times (10 - R_{ext}) / 10 \text{ [V]}$$

$$R_{ext} = 10 \times (E_{rtg} - E_o) / E_{rtg} \text{ [V]}$$

---

### NOTE

- If Rext comes loose when using the 10 kΩ → MAX OUT CV mode, excessive voltage may be applied to the load. For your safety, it is recommended that fail-safe 10 kΩ → 0 OUT CV mode be used.
  - If you are using fixed resistors for Rext and controlling the output voltage by switching through them, use a short-circuit or continuous type switch.
- 



### External resistance (Rext) connection

For Rext, use a 1/2 W or larger metal film or wire-wound type resistor with good temperature coefficient and small aging effect.

To minimize the influence of noise on the output, use a two-core shielded wire or a twisted-pair wire to connect the control terminals and Rext. Make the wires as short as possible. Susceptibility to the effects of noise increases as the wires get longer. When wires are long, proper operation may be hindered even if a cable with anti-noise measures is used.

When using a shielded cable, connect the shield to the - (neg.) output terminal.

Pins 1 and 6 of the J1 connector are used.




Fig. 3-9 Connection of the output voltage control using Rext

---

## 3.5 Output Current Control

This section explains the method used to control the output current using an external voltage ( $V_{ext}$ ) in the range 0 V to approx. 10 V or an external resistor ( $R_{ext}$ ) in the range 0 k $\Omega$  to approx. 10 k $\Omega$  .



### **WARNING** Possible electric shock.

- **The insulation of the  $V_{ext}$  or  $R_{ext}$  and the connected wire should be greater than the isolation voltage of the PWR. For the isolation voltage of each model, see Chapter 6 “Specifications.”**
  - **When using shielded wires for the connection, protect the uncovered section of the shielded wire by using insulation tubes with a withstand voltage greater than the isolation voltage of the PWR.**
- 

### 3.5.1 External Voltage ( $V_{ext}$ ) Control



Page 2-23

To control the output current using  $V_{ext}$ , set the CC control source in the CONFIG settings to external voltage control (C-2: 1).

The output current ( $I_o$ ) varies in the range of 0 to the maximum preset current ( $I_{max}$ ) on the L type by setting the external voltage ( $V_{ext}$ ) in the range of 0 V to 10 V. On the M/H type,  $I_{max}$  is the rated output current ( $I_{rtg}$ ).

$$I_o = I_{max} \times V_{ext} / 10 \text{ [A]} \quad V_{ext} = 10 \times I_o / I_{max} \text{ [A]}$$



- The signal wire may burn out. Leave the  $V_{ext}$  output floating.
  - If the polarity is reversed, the PWR may break. Make sure the polarity of  $V_{ext}$  is correct.
  - The PWR may break. Do not apply voltage or reverse voltage exceeding 10.5 V across the external voltage control pins.
- 





## External voltage source (Vext) connection

Use a low-noise and stable voltage source for Vext. The noise in Vext is multiplied by the amplification factor of the PWR and appears at the PWR output. Thus, the output ripple noise may not meet the PWR's specifications.

To minimize the influence of noise on the output, use a two-core shielded wire or a twisted-pair wire to connect the control terminals and Vext. Make the wires as short as possible. Susceptibility to the effects of noise increases as the wires get longer. When wires are long, proper operation may be hindered even if a cable with anti-noise measures is used.

When using a shielded cable, connect the shield to the - (neg.) output terminal. If the shield needs to be connected to the Vext end, see “Precautions to be taken when using the external voltage (Vext).”

Pins 1 and 5 of the J1 connector are used. The input impedance across the external voltage control pins is approximately 30 k $\Omega$ .

See  
Page 3-9




Fig. 3-10 Connection of the output current control using Vext

---

## 3.5.2 External Resistance (Rext) Control



Page 2-23

To control the constant current using Rext, select the CC control source in the CONFIG settings from the following two modes.

- External resistance control 10 kΩ → MAX OUT (C-2: 2)

The output current (Io) varies in the range of 0 to the maximum output current (Imax) on the L type by setting the external resistance (Rext) in the range of 0 kΩ to 10 kΩ. On the H type, Imax is the rated output current (Irtg).

$$I_o = I_{max} \times R_{ext} / 10 \text{ [A]} \quad R_{ext} = 10 \times I_o / I_{max} \text{ [A]}$$

- External resistance control 10 kΩ → 0 OUT (FAIL SAFE) (C-2: 3)

The output current (Io) varies in the range of the maximum output current (Imax) to 0 on the L type by setting the external resistance (Rext) in the range of 0 kΩ to 10 kΩ. On the M/H type, Imax is the rated output current (Irtg).

$$I_o = I_{max} \times (10 - R_{ext}) / 10 \text{ [A]}$$

$$R_{ext} = 10 \times (I_{max} - I_o) / I_{max} \text{ [A]}$$

---

### NOTE

- If Rext comes loose when using the 10 kΩ → MAX OUT CC mode, excessive current may flow through the load. For your safety, it is recommended that fail-safe 10 kΩ → 0 OUT CC mode be used.
  - If you are using fixed resistors for Rext and controlling the output voltage by switching through them, use a short-circuit or continuous type switch.
- 



### External resistance (Rext) connection

For Rext, use a 1/2 W or larger metal film or wire-wound type resistor with good temperature coefficient and small aging effect.

To minimize the influence of noise on the output, use a two-core shielded wire or a twisted-pair wire to connect the control terminals and Rext. Make the wires as short as possible. Susceptibility to the effects of noise increases as the wires get longer. When wires are long, proper operation may be hindered even if a cable with anti-noise measures is used.

When using a shielded cable, connect the shield to the - (neg.) output terminal.

Pins 1 and 7 of the J1 connector are used.




Fig. 3-11 Connection of the output current control using Rext

---

## 3.6 Controlling the Output On/Off

This section explains the method used to control the on/off of the output by using an external contact.



### **WARNING** Possible electric shock.

- **The insulation of the external contact (S) and the connected wire should be greater than the isolation voltage of the PWR.**  
**For the isolation voltage of each model, see Chapter 6 “Specifications.”**
- **When using shielded wires for the connection, protect the uncovered section of the shielded wire by using insulation tubes with a withstand voltage greater than the isolation voltage of the PWR.**

---

To minimize the influence of noise on the output, use a two-core shielded wire or a twisted-pair wire to connect the control terminals and the external contact. Make the wires as short as possible. Susceptibility to the effects of noise increases as the wires get longer. When wires are long, proper operation may be hindered even if a cable with anti-noise measures is used.

When using a shielded cable, connect the shield to the - (neg.) output terminal.

To control the output on/off using external contact, select the external control logic setting of output on/off in the CONFIG settings from the following two modes.

- Turn the output on with a high signal (C-6: 0)

The output turns on when pin 3 of the J1 connector is set high (TTL level) or opened.

- Turn the output on with a low signal (C-6: 1)


The output turns on when pin 3 of the J1 connector is set low (TTL level).

See

Page 2-26



If the output is set to off using an external contact, the OUTPUT switch on the front panel is invalid. If you are not controlling the output using an external contact, turn the output on by setting the external control logic setting of output on/off in the CONFIG settings to high (C-6: 0).



**Fig. 3-12 Output on/off control**  
(example in which the output is on at high)

## External contact connection

Pins 2 and 3 of the J1 connector are used.

The release voltage across pins 2 and 3 is approx.  $5\text{ V} \pm 5\%$  maximum, and the short circuit current is approx.  $500\ \mu\text{A} \pm 5\%$  maximum. (The internal circuit is pulled up to 5 V through 10 k $\Omega$ .)

Use parts with a contact rating of 5 Vdc and 10 mA for the external contact.

If multiple units are used under floating conditions and a single external contact is used to turn on/off the output, isolate the signal to each unit such as by using a relay on the external contact signal.




Fig. 3-13 On/off control connection using an external contact

### ■ For long-distance wiring

When wiring over a great distance, use a small relay and extend the coil end of the relay.




Fig. 3-14 On/off control using an external contact (for long-distance wiring)

## 3.7 Shutdown Control

This section explains the method used to trip the breaker (turn the POWER switch off) or turn the output off using external contact.



**WARNING**

### Possible electric shock.

- **The insulation of the external contact (S) and the connected cable should be greater than the isolation voltage of the PWR.**  
**For the isolation voltage of each model, see Chapter 6 “Specifications.”**
- **When using shielded wires for the connection, protect the uncovered section of the shielded wire by using insulation tubes with a withstand voltage greater than the isolation voltage of the PWR.**

To minimize the influence of noise on the output, use a two-core shielded wire or a twisted-pair wire to connect the control terminals and the external contact. Make the wires as short as possible. Susceptibility to the effects of noise increases as the wires get longer. When wires are long, proper operation may be hindered even if a cable with anti-noise measures is used.

When using a shielded cable, connect the shield to the - (neg.) output terminal.



Page 2-27

To control the shutdown using an external contact, select the breaker trip setting that is applied when the protection function is activated in the CONFIG settings from the following two modes.

- Trip (C-8: 0)

The breaker trips when pin 10 of the J1 connector is set low (TTL level). To recover, set pin 10 high (TTL) or open the pin and turn on the POWER switch.

- Not trip (C-8: 1)

The output turns off when pin 10 of the J1 connector is set low (TTL level). The breaker is not tripped. To recover, set pin 10 high (TTL) or open the pin and turn the POWER switch off and then back on.

## Shutdown control connection

Pins 2 and 10 of the J1 connector are used.

The release voltage across pins 2 and 10 is approx.  $5\text{ V} \pm 5\%$  maximum, and the short circuit current is approx.  $500\ \mu\text{A} \pm 5\%$  maximum. (The internal circuit is pulled up to 5 V through  $10\ \text{k}\Omega$ .)

Use parts with a contact rating of 5 Vdc and 10 mA for the external contact.




Fig. 3-15 Shutdown control connection using an external contact

### ■ For long-distance wiring

When wiring over a great distance, use a small relay and extend the coil end of the relay.




Fig. 3-16 Shutdown control connection using an external contact (for long-distance wiring)



## 3.8 External Monitoring

### External monitoring of the output voltage and output current

The J1 connector consists of monitor outputs for output voltage and output current.

Table 3-3 Monitor output of output voltage and output current

Pin No.	Signal Name	Description
1	A COM	Common for remote control input. Common for output monitor.
8	V MON	Monitor output of output voltage. 0 to approx. 10 V for 0 to the rated output voltage.
9	I MON	Monitor output of output current. L type: 0 to approx. 10 V for 0 to the maximum output current. H type: 0 to approx. 10 V for 0 to the rated output current.

---

**⚠ CAUTION** • Shorting V MON and I MON to A COM can cause damage to the PWR.

---

Monitor output rating

Output impedance: 1 k $\Omega$  or less

Maximum output current: Approx. 10 mA

The monitor outputs are used to monitor the DC voltage (mean value). They cannot be used to accurately monitor the AC components (ripple, transient response, etc.) of the actual output voltage or current.

## External monitoring of the operating status

The J1 connector consists of status outputs that is used to externally monitor the operating status of the PWR. The following five status outputs are available.

The outputs are open collector outputs of photocouplers; they are insulated from the internal circuits of the PWR.

The maximum rating of each signal terminal is as follows:

- Maximum voltage: 30 V
- Maximum current (sink): 8 mA

Table 3-4 Status output

Pin No.	Signal Name	Description	Circuit
17	STATUS COM	Common for status output. Photocoupler emitter output.	
18	CV STATUS	Set to low level when in constant voltage mode. Photocoupler collector output.	
19	CC STATUS	Set to low level when in constant current mode. Photocoupler collector output.	
20	ALM STATUS	Set to low level when a protection function is activated. Photocoupler collector output.	
21	OUT ON STATUS	Set to low level when output is turned on. Photocoupler collector output.	
22	PWR ON/OFF STATUS*1	Set to low level when the POWER switch is on (PWR ON STATUS) or when the POWER switch is turned off (POWER OFF STATUS: approx. 0.5 to 3 seconds). Photocoupler collector output.	

- \*1. Status signal setting of the output on/off in the CONFIG settings is used to select whether to output a low level signal when the output is on (C-9: 0) or when the output is off (C-9: 1).



## Parallel/Series Operation

This chapter describes the functions of the master-slave parallel/serial operation and the connection, setup, and operation procedures.

In master-slave operation, one of the PWRs is made the master unit and connected to the same model as slave units. The master unit is used to control the entire system.

During series/parallel operation, the setting accuracy of master and slave units is the same as that of single units. The error in preset values between master and slave units is within approx. 3 %.

## 4.1 Master-Slave Series Operation (L Type Only)



- **Master-slave series operation is not possible on the M/H type. If connected in series, the output voltage will exceed the isolation voltage creating a dangerous condition.**

Up to two units can be connected in series. The total of the output voltages of the two units in master-slave series operation is supplied to the load.

### 4.1.1 Functions (Series Operation)

The functions in master-slave series operation are as follows.

#### Voltage display and current display

The current is displayed only on the master unit. The voltage is displayed both on the master unit and slave unit. Sum the voltages of the master and slave units. The power can be displayed only on the master unit. The power of the entire system cannot be displayed.




Fig. 4-1 Panel display example during series operation

## Remote sensing

Cannot be used.

## External control



Can be used only on the master unit.



## External monitoring

Page 3-23



**WARNING** • **Be careful of short-circuits and electric shock while monitoring signals. The common electric potential of the output voltage and output current monitor signals during master-slave series operation are different between the master unit and slave unit.**

- External monitoring of output voltage (V MON)

The output voltage of the master unit and that of the slave unit can be monitored. For the total output voltage, sum the monitor values of the master and slave units.

- External monitoring of output current (I MON)

Can be monitored only on the master unit.

- Status monitoring

The status of the constant voltage operation (CV STATUS), constant current operation (CC STATUS), output on, power on, and alarm can be monitored on the master unit and slave unit.

## Alarm

If an alarm is detected, the units behave as follows:

- Slave unit

An alarm is activated independently. Then, the output is turned off, or the breaker is tripped.

- Master unit

If an alarm is detected on the master unit, the alarm on the slave unit is also activated, and the output of the entire system is turned off or the breaker is tripped.



See

Page 2-27

You can select whether to trip the breaker (C-8: 0/1) when an alarm is detected.

### ■ Clearing the alarm

See

Page 2-16

Page 4-7

Turn off the POWER switch of the slave unit first followed by the master unit. After removing all the causes of alarm, turn on the POWER of the master unit first followed by the slave unit.

## 4.1.2 Connection (Series Operation)

Connect two PWRs of the same model.

### Connecting the signal wires (series operation)

See

Page 3-2

The connector needed to connect the J1 connector is not provided. For detail, see “3.2 J1 connector.”

#### **⚠ WARNING**

**Possible electric shock.**

- **The J1 connector contains pins that are at the same electric potential as the output terminal. If you are not using the J1 connector, be sure to insert the protective socket provided.**
- **Be sure to use the protective cover on the sockets.**





Fig. 4-2 Connection for series operation

Connect the J1 connectors on the rear panel of the master and slave units as shown in  4-2.

## Load connection (series operation)

Connect the load as shown below. For detail of the output terminal connection, see the setup guide.



- **Possible electric shock. Be sure to turn the POWER switch off before touching the output terminal. Be sure to attach the OUTPUT terminal cover after wiring the load.**





Fig. 4-3 Load connection example for series operation

- 1 Turn off the POWER switches on all PWR Series power supply units to be connected in series.
- 2 Remove the OUTPUT terminal cover.
- 3 Connect the output terminal (+ or -) of the master or slave unit to the chassis terminal.

If you are using the master and slave units under floating conditions, do not connect the output terminal to the chassis terminal.

- 4 As shown in  4-3, connect the load wires of the master and slave units to the load or the relay terminal block.

Use load wires with sufficient current capacity. Wire the connection cables between the power supply units as thick and as short as possible. If the voltage drop in the output cable is large, the difference in the potential and the load effect between power supply units becomes large.

- 5 Attach the OUTPUT terminal cover.

## 4.1.3 Setup (Series Operation)

### ■ Setting the overvoltage protection (OVP) and overcurrent protection (OCP)



Page 2-17

Set the OVP and OCP on both the master unit and slave unit.

The OVP is set to one-half the voltage to be protected to the master unit and slave unit.

Set the OVP/OCP trip point of the slave unit slightly higher than that of the master unit, so that the OVP/OCP function of the master unit is activated first. If the OVP/OCP trip point of the slave unit is set lower than that of the master unit, the overvoltage/overcurrent protection of the slave unit activates first, and the output of the slave unit is turned off. The output of the master unit is not turned off even if the slave unit turns off.

### Setup Procedure (Series Operation)

By factory default, the PWR is set to master.




Fig. 4-4 Specifying the slave unit for series operation

- 1 Set the overvoltage protection and overcurrent protection.  
You cannot set the OVP or OCP after specifying the master unit or slave unit. Set the OVP/OCP trip point of the slave unit slightly higher than the trip point of the master unit.
- 2 Specify master unit (C-5: 0) or slave unit (C-5: 2) in the serial/parallel master-slave operation setting of the CONFIG settings.

If slave unit is specified, the CC/CV control source (C-1/C-2) is set to local.



---

#### 4.1.4 Procedure (Series Operation)

The power supplies may not operate properly if the procedure is not followed.

##### Turning the power on

**1** Turn on the POWER switch on the master unit.

**2** Turn on the POWER switch on the slave unit.


**3** Carry out normal operations on the master unit.

The panel operation on the slave units is disabled. Turn the output on/off on the master unit.

##### Turning the power off

**1** Turn off the POWER switch on the slave unit.

**2** Turn off the POWER switch on the master unit.

- 
-  **CAUTION** • When turning the POWER switch off and then back on, allow at least 10 seconds after the panel display lights out. Repeated on/off of the POWER switch at short intervals can cause damage to the inrush current limiter and shorten the service life of the POWER switch and internal input fuse.
-

## 4.2 Master-Slave Parallel Operation

The output current can be expanded using master-slave parallel operation (maximum output current: the rated output current of a unit  $\times$  number of units connected in parallel).

Maximum number of units that can be connected is five including the master.

### 4.2.1 Functions (Parallel Operation)

The functions in master-slave parallel operation are as follows.

#### ■ Voltage display and current display

The voltage is displayed only on the master unit. The current is displayed both on the master unit and slave units. Sum the current of the master and slave units.

The power can be displayed only on the master unit. The power of the entire system cannot be displayed.




Fig. 4-5 Panel display during parallel operation

#### Remote sensing

Can be used only on the master unit.

See

Page 2-28

#### External control

Can be used only on the master unit.

See

?3 ?

- 
- ⚠ CAUTION** • Do not connect the common wires of the master and slave monitors outside the PAT. If the wire connecting the load comes loose, the common wire will break.
- 

- External monitoring of output voltage (V MON)  
Can be monitored on the master unit.
- External monitoring of output current (I MON)  
The output current of each master and slave unit can be monitored. For the total output current, sum the monitor values of the master and slave units.
- Status monitoring  
The status of the constant voltage operation (CV STATUS), constant current operation (CC STATUS), output on, power on, and alarm can be monitored on the master unit and slave unit. However, slave units always output the status of the constant current operation.

---

## Alarms

If an alarm is detected, the units behave as follows:

- Slave unit

An alarm is activated independently. Then, the output is turned off, or the breaker is tripped.

- Master unit

If an alarm is detected on the master unit, the alarm on the slave unit is also activated, and the output of the entire system is turned off or the breaker is tripped.



Page 2-27

You can select whether to trip the breaker (C-8: 0/1) when an alarm is detected.

### ■ Clearing the alarm



Page 2-16

Page 4-15

Turn off the POWER switch of the slave unit first followed by the master unit. After removing all the causes of alarm, turn on the POWER of the master unit first followed by the slave unit.



## 4.2.2 Connection (Parallel Operation)

Up to 5 units can be connected including the master unit.

### Connecting the signal wires (parallel operation)

An example in which two slave units are connected is given below.

See  
Page 3-2

The connector needed to connect the J1 connector is not provided. For detail, see “3.2 J1 connector.”



#### **WARNING** Possible electric shock.

- **The J1 connector contains pins that are at the same electric potential as the output terminal. If you are not using the J1 connector, be sure to insert the protective socket provided.**
- **Be sure to use the protective cover on the sockets.**




Fig. 4-6 Connection for parallel operation (two slave units)

Connect the J1 connectors on the rear panel of the master unit, slave unit 1, and slave unit 2 as shown in Fig. 4-6. To connect 4 or more PWRs in parallel, connect the slave units in the same fashion as the connection between slave unit 1 and slave unit 2.

## Connecting the load (parallel operation)

Connect the load as shown below. For detail of the output terminal connection, see the setup guide.



**WARNING**

- **Possible electric shock. Be sure to turn the POWER switch off before touching the output terminal. Be sure to attach the OUTPUT terminal cover after wiring the load.**



**CAUTION**

- When connecting the output terminal to the chassis terminal, be sure that the output terminal of the same polarity (positive or negative) for both the master and slave units is connected to the chassis terminal. If you connect the output terminal of different polarities for the master and slave units, the output is short-circuited through the GND cable of the power cord. This not only impedes the retrieval of correct voltage but also may burn out the chassis terminal cable.




Fig. 4-7 Load connection example for parallel operation (two slave units)


**1** Turn off the POWER switches on all PWR Series power supply units to be connected in parallel.

**2** Remove the OUTPUT terminal cover.

**3** Connect the output terminals (+ or –) of the master and slave units to the chassis terminal.

Use the same polarities for the output terminals of the master and slave units. If you are using the master and slave units under floating conditions, do not connect the output terminals to the chassis terminal.

**4** Connect the load wires to the output terminals of the master and slave units.

**5** As shown in  4-7, connect the load wires of the master and slave units to the load or the relay terminal block.

Use load wires with sufficient current capacity. In addition, use the shortest load wires of the same length and cross-sectional area from each power supply to the load.

Wire the signal cable of the J1 connector and load cables as far apart as possible.

**6** Attach the OUTPUT terminal cover.

To connect 4 or more PWRs in parallel, connect the slave units in the same fashion as the connection between slave unit 1 and slave unit 2.

## 4.2.3 Setup (Parallel Operation)

### ■ Setting the overvoltage protection (OVP) and overcurrent protection (OCP)



Page 2-17

Set the OVP and OCP on both the master unit and slave units.

Set the value equal to the current to be protected divided by the number of units connected in parallel for OCP.

Set the OVP/OCP trip point of the slave units slightly higher than that of the master unit, so that the OVP/OCP function of the master unit is activated first. If the OVP/OCP trip point of a slave unit is set lower than that of the master unit, the overvoltage/overcurrent protection of the slave unit activates first, and the output of the slave unit is turned off. The output of the master unit is not turned off even if the slave unit turns off.

### Setup Procedure (Parallel Operation)

By factory default, the PWR is set to master.




Fig. 4-8 Specifying the slave unit for parallel operation

#### 1 Set the overvoltage protection and overcurrent protection.

You cannot set the OVP or OCP after specifying the master unit or slave unit. Set the OVP/OCP trip point of the slave units slightly higher than the trip point of the master unit.

#### 2 Specify master unit (C-5: 0) or slave unit (C-5: 1) in the serial/parallel master-slave operation setting of the CONFIG settings.

If slave unit is specified, the CC/CV control source (C-1/C-2) is set to local.



---

## 4.2.4 Procedure (Parallel Operation)

The power supplies may not operate properly if the procedure is not followed.


### Turning the power on

- 1 Turn on the POWER switch on the master unit.
- 2 Turn on the POWER switch on the slave units.
- 3 Carry out normal operations on the master unit.

The panel operation on the slave units is disabled. Turn the output on/off on the master unit.

### Turning the power off

- 1 Turn off the POWER switch on the slave units.
- 2 Turn off the POWER switch on the master unit.

- 
-  **CAUTION** • When turning the POWER switch off and then back on, allow at least 10 seconds after the panel display lights out. Repeated on/off of the POWER switch at short intervals can cause damage to the inrush current limiter and shorten the service life of the POWER switch and internal input fuse.
-





## **Maintenance**


This chapter describes maintenance and inspection of the PWR.

---

## 5.1 Inspection


Periodic inspection is essential to maintain the initial performance of the PWR over an extended period.

Check for tears in the power cord insulation, cracks in the plug, and breaks in the terminal block.

- 
-  **WARNING** • **Tears in the insulation coating of the power cord may cause electric shock or fire. If a tear is found, stop using it immediately.**
- 


To purchase accessories or options, contact your Kikusui agent or distributor.

### 5.1.1 Cleaning

- 
-  **WARNING** • **Possible electric shock. When performing maintenance work, be sure to turn off the POWER switch and remove the power cord plug or turn off the switchboard.**
- 

#### Cleaning the Panels

If the panel needs cleaning, gently wipe using a soft cloth with water-diluted neutral detergent.

- 
-  **CAUTION** • **Do not use volatile chemicals such as benzene or thinner. They may discolor the surface, erase printed characters, or cloud the LCD.**
-

## Cleaning the dust filter

Dust filters are furnished on the inside of the louver and at the bottom of the operation panel. Periodically clean the filter to prevent clogging.

- ⚠ CAUTION**
- Clogged dust filters hinder the cooling of the inside of the unit and can cause malfunction and shortening of the service life.
  - When the PWR is in operation, air is sucked through the dust filter to cool the inside. If moisture is present in the dust filter, the temperature or humidity inside the PWR increases and may cause a malfunction.

### Dust filter inside the louver

- 1 Pull down the top section of the louver while pulling the bottom step toward you.




Fig. 5-1 Louver removal

- 2 Remove the dust filter from the inside of the louver and clean it.

Dispose of foreign particles and dust from the dust filter using a vacuum cleaner. If the filter is extremely dirty, clean it using a water-diluted neutral detergent and dry it completely.

### 3 Attach the dust filter to the louver.

Attach it so that the dust filter fits inside the hooks of the louver.




Fig. 5-2 Dust filter attachment

### 4 Align and set the hooks of the louver to the panel grooves. While pressing the fourth level from the bottom, slide the louver upward to attach it to the panel.




Fig. 5-3 Louver attachment

### Dust filter below the operation panel

This dust filter cannot be removed. Dispose of foreign particles and dust from the filter using a vacuum cleaner.




Fig. 5-4 Dust filter below the operation panel

## 5.2 Calibration

The PWR is shipped after carrying out appropriate calibrations. We recommend periodic calibration to maintain the performance over an extended period.

For calibration, contact your Kikusui agent or distributor.

If you are going to calibrate the PWR yourself, follow the procedures below. All of the calibration items of the PWR are described.

### 5.2.1 Calibration Overview

The following four calibration items are available.

- Output voltage
- Output current
- OVP
- OCP

Be sure to perform calibration on both the offset and full scale. The PWR outputs approximately 10 % of the rated output during offset calibration and approximately the rated output during full scale calibration.

#### Test equipment required

For calibration, the following equipment is necessary.

- DC voltmeter (DVM) with measuring accuracy of 0.02 % or better.
- Shunt (see Table 5-1).

Table 5-1 Recommended shunt

Model		Shunt	
		Rating	Tolerance
400 W type	PWR400L	50 A / 50 mV (1 mΩ)	< 0.1 %
	PWR400M	10 A / 50 mV (5 mΩ)	
	PWR400H	5 A / 50 mV (10 mΩ)	
800 W type	PWR800L	100 A / 50 mV (0.5 mΩ)	
	PWR800M	20 A / 50 mV (2.5 mΩ)	
	PWR800H	5 A / 50 mV (10 mΩ)	
1600 W type	PWR1600L	200 A / 50 mV (0.25 mΩ)	
	PWR1600M	50 A / 50 mV (1 mΩ)	
	PWR1600H	10 A / 50 mV (5 mΩ)	

## Environment

Perform calibration under the following environment.

- Temperature:  $23\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$
- Relative humidity: 80 %rh or less

To minimize the calibration error due to initial drift, warm up the PWR for at least 30 minutes before calibration. Warm up the DVM and shunt for their appropriate time.

### 5.2.2 Voltage Calibration




Fig. 5-5 Panel display example and connection for voltage calibration

Be sure to carry out the calibration items to the last step. If you move to a different type of calibration in the middle of another calibration or if you turn the POWER switch off, the calibration is invalid.

To exit from the calibration procedure, turn off the POWER switch.



## Calibration of the output voltage offset and full scale

**1** Turn the POWER switch off, and connect a DVM to the output terminal.

**2** While holding down the SET switch, turn on the POWER switch.

The ammeter shows “CAL.” Hold down the SET switch until “CAL” appears. Warm up the equipment adequately including the DVM.

**3** Press the VOLTAGE switch to enter the output voltage offset calibration mode.

The voltmeter shows “OF 0.”

**4** Turn the OUTPUT switch on, and turn the setting knob so that the DVM reading is equal to 10 % of the rated output voltage.

The PWR outputs approximately 10 % of the rated output voltage. Turning the setting knob while holding down the SHIFT switch increases the resolution.

**5** Turn off the OUTPUT switch.

The offset is calibrated, and the voltmeter shows “OF 1.”

**6** Press the VOLTAGE switch to enter the output voltage full scale calibration mode.

The voltmeter shows “FS 1.”

**7** Turn the OUTPUT switch on, and turn the setting knob so that the DVM reading is equal to the rated output voltage.

The PWR outputs approximately 100 % of the rated output voltage. Turning the setting knob while holding down the SHIFT switch increases the resolution.

**8** Turn off the OUTPUT switch.

The full scale is calibrated, and the voltmeter shows “FS 3.”

**9** Press the SET switch to store the calibration value.

The calibration values for offset and full scale are stored, and the voltmeter returns to “FS 0.”

---

## Calibration of the OVP (overvoltage protection) offset and full scale

Calibrate the OVP after completing the calibration of the voltage. To continue with the OVP calibration after the voltage calibration, start from step 3 .



Fig. 5-5

**1** Turn the POWER switch off, and connect a DVM to the output terminal.

**2** While holding down the SET switch, turn on the POWER switch.

The ammeter shows “CAL.” Hold down the SET switch until “CAL” appears. Warm up the equipment adequately including the DVM.

**3** Press the OVP switch and then the VOLTAGE switch to enter the OVP offset calibration mode.

The ammeter shows “OVP,” and the voltmeter shows “OF 0”.

**4** Turn on the OUTPUT switch.

The ON indicator blinks, and the calibration starts automatically. When the calibration is complete, the POWER switch is turned off. (This takes 30 s to 60 s.)

**5** While holding down the SET switch, turn on the POWER switch.

Hold down the SET switch until “CAL” appears.

**6** Press the OVP switch and then the VOLTAGE switch to enter the OVP full scale calibration mode.

The ammeter shows “OVP,” and the voltmeter shows “FS 0”.

**7** Turn on the OUTPUT switch.

The ON indicator blinks, and the calibration starts automatically. When the calibration is complete, the POWER switch is turned off. (This takes 30 s to 60 s.)



## 5.2.3 Current Calibration





Fig. 5-6 Panel display example and connection for current calibration

Be sure to carry out the calibration items to the last step. If you move to a different type of calibration in the middle of another calibration or if you turn the POWER switch off, the calibration is invalid.

To exit from the calibration procedure, turn off the POWER switch.

---

## Calibration of the output current offset and full scale

**1** Turn the POWER switch off, and connect a shunt and a DVM to the output terminal.

**2** While holding down the SET switch, turn on the POWER switch.

The voltmeter shows “CAL.” Hold down the SET switch until “CAL” appears. Warm up the equipment adequately including the DVM and shunt.

**3** Press the CURRENT switch to enter the output current offset calibration mode.

The ammeter shows “OF 0.”

**4** Turn the OUTPUT switch on, and turn the setting knob so that the DVM reading is equal to 10 % of the rated output current.

The PWR outputs approximately 10 % of the rated output current. Turning the setting knob while holding down the SHIFT switch increases the resolution.

**5** Turn off the OUTPUT switch.

The offset is calibrated, and the ammeter shows “OF 1.”

**6** Press the CURRENT switch to enter the output current full scale calibration mode.

The ammeter shows “FS 1.”

**7** Turn the OUTPUT switch on, and turn the setting knob so that the DVM reading is equal to the rated output current.

The PWR outputs approximately 100 % of the rated output current. Turning the setting knob while holding down the SHIFT switch increases the resolution.

**8** Turn off the OUTPUT switch.

The full scale is calibrated, and the ammeter shows “FS 3.”

**9** Press the SET switch to store the calibration value.

The calibration values for offset and full scale are stored, and the ammeter returns to “FS 0.”



## Calibration of the OCP (overcurrent protection) offset and full scale

Calibrate the OCP after completing the calibration of the current. To continue with the OCP calibration after the current calibration, start from step 3 .



Fig. 5-6

**1** Turn the POWER switch off, and connect a shunt and a DVM to the output terminal.

**2** While holding down the SET switch, turn on the POWER switch.

The voltmeter shows “CAL.” Hold down the SET switch until “CAL” appears. Warm up the equipment adequately including the DVM and shunt.

**3** Press the OCP (SHIFT+OVP) switch and then the CURRENT switch to enter the OCP offset calibration mode.

The voltmeter shows “OCP,” and the ammeter shows “OF 0”.

**4** Turn on the OUTPUT switch.

The ON indicator blinks, and the calibration starts automatically. When the calibration is complete, the POWER switch is turned off. (This takes 60 s to 90 s.)

**5** While holding down the SET switch, turn on the POWER switch.

Hold down the SET switch until “CAL” appears.

**6** Press the OCP (SHIFT+OVP) switch and then the CURRENT switch to enter the OCP full scale calibration mode.

The voltmeter shows “OCP,” and the ammeter shows “FS 0”.

**7** Turn on the OUTPUT switch.

The ON indicator blinks, and the calibration starts automatically. When the calibration is complete, the POWER switch is turned off. (This takes 60 s to 90 s.)

## 5.3 Troubleshooting

If you have problems operating the PWR, check whether any of the items below apply to your case. In some cases, the problem can be solved quite easily.



Page 2-32

If none of the items apply to your case, we recommend that you initialize the PWR to factory default condition. If the remedy does not correct the problem, contact your Kikusui agent or distributor.

STUP: See the setup guide.

### ■ The power does not turn on.

Check Item	Cause and Remedy	See Page
Is the wiring to the L, N, and GND of the AC INPUT terminal correct?	Connect it correctly.	STUP
Is the power cord is broken?	Replace the power cord with a new one.	STUP

### ■ Output does not turn on even when the OUTPUT switch is turned on.

Check Item	Cause and Remedy	See Page
Is the output voltage set to 0 V, and the output current set to 0 A?	Set the output voltage and output current to appropriate values.	2-13
Are you performing output on/off control using an external contact?	Yes Turn the output on using the external contact.	3-18
	No Set the external control logic setting of the output on/off to “turn the output on with a high signal” (C-6: 0).	2-23
Is the CV/CC control source set to external control?	Set it to panel control (C-1: 0 and C-2: 0).	2-23



■ The ALM indicator illuminates when the OUTPUT switch is turned on.

Check Item	Cause and Remedy	See Page
Is the OVP trip point set less than or equal to the output voltage?	Set the OVP trip point to a voltage greater than or equal to the output voltage.	2-18
Is the OCP trip point set less than or equal to the output current?	Set the OCP trip point to a current greater than or equal to the output current.	2-19
Is the remote sensing function turned on?	If you are not using the remote sensing function, turn off remote sensing (C-3: 0) in the CONFIG settings.	2-23
Is the polarity of remote sensing cable connection reversed?	The polarity of the remote sensing cable may be reversed, or the ends may be shorted. Check the load wire.	2-29
Are you using remote sensing with a long load wire?	Set up the environment so that the voltage drop in the load wire is within the compensation voltage range (0.6 V for a single line).	2-29
Is the control cable loose in the external control?	Connect it correctly.	第 3 章
Is the external voltage excessive in the external control?	Apply the correct voltage.	3-10 3-14
Is the internal temperature is abnormally high?	The overheat protection function is activated. Check the operating environment. The dust filter may be clogged, or the fan may be broken. Check them.	2-21

■ The ALM indicator illuminates when the load is changed.

Check Item	Cause and Remedy	See Page
Is a large external voltage applied such as with a battery load?	The overvoltage protection function or the overcurrent protection function may be activated. Check them.	2-15
Is the actual output is higher than the preset voltage shown on the panel?	The PWR may be overloaded. Check the load.	
Is a special load is connected?		

### ■ The ALM indicator blinks.

Check Item	Cause and Remedy	See Page
Did the load resistance change?	The POWER LIMIT function was activated as a result of the change in the load resistance. This is not a malfunction.	2-22
Are you using the PWR in the extended operating area?	The ALM indicator blinks when operating in the extended operating area. This is not a malfunction.	2-11

### ■ Unable to set the output voltage or output current.

Check Item	Cause and Remedy	See Page
Are you trying to set a voltage higher than the OVP trip point?	Change the OVP trip point.	2-18
Are you trying to set a current higher than the OCP trip point?	Change the OCP trip point.	2-19

### ■ Unable to operate the panel switch.

Check Item	Cause and Remedy	See Page
Is the LOCK switch illuminated?	Release the panel operation lock.	2-28

### ■ The output ripple is large.

Check Item	Cause and Remedy	See Page
Is the input voltage outside the range?	Supply a voltage that is within the input voltage range.	6-3
Is there a source of strong magnetic or electrical field nearby?	Take measures such as moving the PWR away from such generating sources and using twisted cables.	–
Is the external voltage noise is large during external control?	Take measures against noise.	–
Is the remote sensing function turned on?	If you are not using the remote sensing function, turn off remote sensing (C-3: 0) in the CONFIG settings.	2-23



### ■ The output is unstable.

Check Item	Cause and Remedy	See Page
Is the operation mode switching from CV to CC or CC to CV?	Change the setting (output voltage or output current) that is limiting the output to a value greater than the present setting. If the preset value is at maximum, you must use a power supply with a larger output voltage or current.	2-13
Are you using master-slave operation?	The performance degrades slightly during master-slave parallel operation.	第 4 章
Is the remote sensing function turned on?	If you are not using the remote sensing function, turn off remote sensing (C-3: 0) in the CONFIG settings.	2-23
Did 30 minutes pass since the power was turned on?	Warm up (power turned on) the PWR for at least 30 minutes.	-
Are both CV and CC indications illuminated?	If the output is oscillating when using remote sensing, insert a capacitor across the load. The internal circuitry may have malfunctioned. Immediately stop the use of the PWR and request repairs.	2-29
Does the sensing wire or load wire have poor contact or is the cable broken?	Turn off the POWER switch and check the wiring.	2-29
Does the load current have peaks or is it pulse-shaped?	The peak value may be exceeding the preset current. Increase the preset current or increase the current capacity.	2-13

### ■ The power turns off immediately even when it is turned on.

Check Item	Cause and Remedy	See Page
Is the output status setting at power-on set to "output on at power-on" (C-4: 1)?	The protection function is activated. Turn the POWER switch on while holding down the OUTPUT switch to power up with the output temporarily turned off. Eliminate the cause that is activating the protection function.	2-15 2-23

---

■ The PWR cannot be controlled remotely.

Check Item	Cause and Remedy	See Page
Is the CV/CC control source set to external control?	Set it to panel control (C-1: 0 and C-2: 0).	2-23





# Specifications

This chapter lists the specifications.

---

Unless specified otherwise, the specifications are for the following settings and conditions.

- The load is a pure resistance.
- The warm-up time is 30 minutes (with current flowing).
- After warm-up is complete, the PWR must be calibrated correctly according to the procedures given in the operation manual in a  $23\text{ }^{\circ}\text{C} \pm 5\text{ }^{\circ}\text{C}$  environment.
- typ: A typical value. It does not guarantee the performance.
- rtg: Indicates the rated value.
- rdng: Indicates the read value.
- The PWR is capable of operating in a wide range of output voltage and output current combinations within the rated output power. However, the current (or voltage) that can be delivered at the rated output voltage (or rated output current) is limited by the rated output power.
- The current (voltage) that can be output at the rated output voltage (or rated output current) is as follows:
  - Maximum output current at the rated output voltage is equal to the rated output power divided by the rated output voltage
  - Maximum output voltage at the rated output current is equal to the rated output power divided by the rated output current
- Rated load and no load are defined as follows:
  - During constant voltage operation  
(Set the preset current to a value greater than the maximum output current at the rated output voltage)
    - Rated load: Refers to a load with a resistance that makes the current that flows when the rated output voltage is applied to be 95 % to 100 % of the maximum output current at the rated output voltage.
    - No load: Refers to a load at which no output current flows or an open load (no load is connected).
  - During constant current operation  
(Set the preset voltage to a value greater than the maximum output voltage at the rated output current)
    - Rated load: Refers to a load with a resistance that makes the voltage drop when the rated output current is supplied to be 95 % to 100 % of the maximum output voltage at the rated output current. The output voltage of the PWR including the voltage drop in the load wire must not exceed the maximum output voltage at the rated output current.
    - No load: Refers to a load with a resistance that makes the voltage drop when the rated output current is supplied to be 10 % of the maximum output voltage or 1 V, whichever is greater, at the rated output current.
- The specifications of the PWR are defined for output terminal on the rear panel. Those on the front panel may not satisfy the specifications.

## Common specifications

Common Specifications			
AC input			
Nominal input rating <sup>*1</sup>	100 Vac to 240 Vac. 50 Hz to 60 Hz, single phase.		
Input voltage range <sup>*1</sup>	85 Vac to 250 Vac.		
Hold-up time for power interruption (MIN)	10 ms (at 50 % load). 5 ms (at rated load).		
Protection function			
OVP (Overvoltage protection)	Protection action	Turns the output off or trips the breaker. <sup>*2</sup> OVP is indicated and ALM illuminates.	
	Selectable range	10 % to 110 % of the rated output voltage.	
	Setting error	±(Rated output voltage × 1.5 %).	
OCP (Overcurrent protection)	Protection action <sup>*3</sup>	Turns the output off or trips the breaker. <sup>*2</sup> OCP is indicated and ALM illuminates.	
	Selectable range	L type	10 % to 176 % of the rated output current.
		M/H type	10 % to 110 % of the rated output current.
Setting error	±(Rated output current × 3 %).		
POWER LIMIT	Protection action <sup>*4</sup>	Power limit at approx. 105 % of the rated output power. The output voltage/current varies depending on the load. ALM blinks.	
OPP (Overpower protection)	Protection action	Turns off the output or trips the breaker when a given time elapses with the output exceeding the power limit <sup>*2</sup> OPP is indicated and ALM illuminates.	
	Value (fixed)	Greater than or equal to approx. 110 % of the rated output power.	
OHP (Overheat protection)	Protection action <sup>*5</sup>	Turns off the output. OHP is indicated and ALM illuminates.	

- \*1. 100 Vac/200 Vac systems, operable without switching
- \*2. Select whether to trip the breaker (C-8: 0/1) when an alarm is detected in the CONFIG settings.  
The specified protection action is common to OVP, OCP, and OPP. It cannot be set separately for OVP, OCP, and OPP.  
The protection function recovers after correcting the abnormal condition and turning on the POWER switch.
- \*3. Protection is not provided for the peak discharge current that is emitted from the built-in capacitor at the output end of the PWR caused by abrupt changes in the load.
- \*4. The specifications of the output voltage or output current are not met in the POWER LIMIT operating area.  
Phenomena such as overshoot and ringing may occur when a switch occurs from constant voltage or constant current operation to power limit operation or vice versa.
- \*5. The protection function recovers after correcting the abnormal condition and turning on the POWER switch.

### Common Specifications

Common Specifications			
Display function			
Voltmeter	Maximum display	L type	99.99 (fixed decimal point).
		M/H type	999.9 (fixed decimal point).
	Display error		$\pm(0.2\% \text{ of rdng} + 5 \text{ digits})$ at $23\text{ }^\circ\text{C} \pm 5\text{ }^\circ\text{C}$ .
Ammeter	Maximum display	Models with a rating less than 10 A	9.999 (fixed decimal point).
		Models with a 10 A rating or greater	99.99 (fixed decimal point).
		Models with a 100 A rating or greater	999.9 (fixed decimal point).
	Display error		$\pm(0.5\% \text{ of rdng} + 5 \text{ digits})$ at $23\text{ }^\circ\text{C} \pm 5\text{ }^\circ\text{C}$ .
Wattmeter PWR DPSSL <sup>*1</sup>		The red LED by the unit (voltage or current) on the display illuminates.	
	Maximum display	400W/800W type	999.9 (displayed on the voltmeter or ammeter).
		1600W type	9999 (displayed on the voltmeter or ammeter).
	Display error		Not defined. (Displays the product of the current and voltage).
Operation display	OUTPUT ON/OFF		Output on: ON (green) illuminates. Output off: OFF (green) illuminates.
	CV operation		CV illuminates (green).
	CC operation		CC illuminates (red).
	ALM operation <sup>*2</sup>		ALM illuminates <sup>*3</sup> (red).
Signal output			
Monitor signal output <sup>*4</sup>	VMON (Voltage)	At rated voltage output	$10.00\text{ V} \pm 0.25\text{ V}$ .
		At 0 V output	$0.00\text{ V} \pm 0.25\text{ V}$ .
	IMON (Current)	At maximum current output <sup>*5</sup>	$10.00\text{ V} \pm 0.25\text{ V}$ .
		At 0 A output	$0.00\text{ V} \pm 0.25\text{ V}$ .
Status signal output <sup>*4, *6</sup>	OUTON STATUS		Turns on when the output is on.
	CV STATUS		Turns on during CV operation.
	CC STATUS		Turns on during CC operation.
	ALM STATUS <sup>*7</sup>		Turns on when an alarm (OVP, OCP, OHP, OPP, or SHUT) is activated.
	PWR OFF STATUS <sup>*8, *9</sup>		Turns on for approximately 0.5 to 3 seconds after the POWER switch is turned off.
	PWR ON STATUS <sup>*9, *10</sup>		Turns on when the POWER switch is on.

Common Specifications			
Control function			
Digital control <sup>*11</sup>		TP-BUS Directly controllable from the PIA4810 or PIA4830.	
External analog control <sup>*4</sup>	EXT-V CV CONT <sup>*12, *13</sup>		0 % to 100 % of the rated output voltage in the range of 0 V to 10 V.
	EXT-R CV CONT <sup>*12</sup>	Normal	0 % to 100 % of the rated output voltage in the range of 0 kΩ to 10 kΩ.
		Fail safe	100 % to 0 % of the rated output voltage in the range of 0 kΩ to 10 kΩ.
	EXT-V CC CONT <sup>*13, *14</sup>		0 % to 100 % of the maximum output current in the range of 0 V to 10 V.
	EXT-R CC CONT <sup>*14</sup>	Normal	0 % to 100 % of the maximum output current in the range of 0 kΩ to 10 kΩ.
		Fail safe	100 % to 0 % of the maximum output current in the range of 0 kΩ to 10 kΩ.
	OUTPUT ON/OFF CONT		Turns on when the TTL level signal is high or when it is low. <sup>*15</sup>
SHUT DOWN		Turn the output off or trip the breaker when the TTL level signal is high. <sup>*16</sup>	

- \*1. Power display and measured value display toggle each time you press the SHIFT+VOLTAGE switch or SHIFT+CURRENT switch. The power value (output value) is shown on the voltmeter or ammeter for the power display.
- \*2. ALM illuminates for approximately 0.5 s to 3 s if the breaker is configured to trip when a protection function is activated (C-8: 0). Other indications are undefined.
- \*3. ALM blinks when operating in the power limit and extended operating area, but the ALM signal is not output.
- \*4. J1 connector on the rear panel.
- \*5. The maximum output current is the rated output current on the M/H type.
- \*6. Photocoupler open collector output.  
Maximum voltage 30 V, maximum current (sink) 8 mA. Insulated from the output and control circuits. Status signals are not mutually insulated.
- \*7. Turns on for approximately 0.5 to 3 s if the breaker is configured to trip when a protection function is activated (C-8: 0).
- \*8. Turns on when the POWER switch is turned off manually or when the breaker trips.
- \*9. Select PWR OFF STATUS (C-9: 1) or PWR ON STATUS (C-9: 0) in the CONFIG settings. The selected signal is output to pin 22 of the J1 connector.
- \*10. Turn on when the input power supply is normal and the POWER switch is on.
- \*11. TP BUS connector on the rear panel.
- \*12. CV external voltage control. Select the control source in the CONFIG settings. The setting error is  $\pm 5$  % of the rated output voltage or  $\pm 5$  % of the maximum output current.
- \*13. The input impedance is approximately 30 kΩ.
- \*14. CC external voltage control. Select the control source in the CONFIG settings. The setting error is  $\pm 5$  % of the rated output voltage or  $\pm 5$  % of the maximum output current. The maximum output current is the rated output current on the M/H type.
- \*15. Select whether to turn on the output at a high signal (C-6: 0) or low signal (C-6: 1) in the CONFIG settings.
- \*16. Select whether to trip the breaker (C-8: 0/1) when an alarm is detected in the CONFIG settings.

### Common Specifications

General		
Environmental conditions	Operating conditions	Indoor use, Overvoltage Category II.
	Operating temperature <sup>*1</sup>	0 °C to +50 °C (32 °F to 122 °F) With output current derating. L type: 45 °C (113 °F) or higher M/H type: 40 °C (104 °F) or higher
	Operating humidity	20 %rh to 85 %rh (no condensation).
	Storage temperature <sup>*2</sup>	-25 °C to +70 °C (-13 °F to 158 °F)
	Storage humidity <sup>*2</sup>	0 %rh to 90 %rh (no condensation).
	Altitude	Up to 2 000 m.
Cooling system		Forced air cooling using a fan. <sup>*3</sup>
Grounding polarity		Negative grounding or positive grounding possible.
Isolation voltage		L/M type: ±600 Vmax. H type: ±1000 Vmax.
Withstand voltage	Across the primary side of the transformer and chassis	No abnormalities at 1500 Vac for 1 minute.
	Across the primary and secondary sides of the transformer	
	Across the secondary side of the transformer and chassis	L/M type: No abnormalities at 600 Vdc for 1 minute. H type: No abnormalities at 1000 Vdc for 1 minute.
Insulation resistance	Across the primary side of the transformer and chassis	500 Vdc, 30 MΩ or more. (at a humidity of 70 %rh or less)
	Across the primary and secondary sides of the transformer	L/M type: 500 Vdc, 30 MΩ or more. H type: 1000 Vdc, 30 MΩ or more. (at a humidity of 70 %rh or less)
	Across the secondary side of the transformer and chassis	
Safety <sup>*4</sup>		Complies with the requirements of the following directives and standards. Low Voltage Directive 2006/95/EC EN 61010-1 Class I Pollution degree 2
Electromagnetic Compatibility (EMC) <sup>*4, *5</sup>		Complies with the requirements of the following directives and standards. EMC Directive 2004/108/EC EN 61326-1 EN 61000-3-2 EN 61000-3-3 Applicable condition All of the wires and wires connected to the PWR are less than 3 m in length.



## Common Specifications

General (cont.)			
Accessories	Operation Manual	1 pc.	
	Power cord*6	400 W type	SVT3 18AWG: 1 pc. with 3 P plug and connector. cable length 2.4 m.
		800 W type	SJT3 14AWG: 1 pc. with 3 P plug and connector. cable length 3 m.
		1600 W type	VCTF3 5.5 mm <sup>2</sup> : 1 pc. without plug and connector. cable length: 3 m. wire color: black, white, green/yellow or green. Cable clamp: 1 set.
	OUTPUT terminal cover	1 set.	
	TP BUS connector	MSTB 2.5/2-ST-5.08 : 1 pc.	
	M4 output terminal screws	M4 x 8 : 2 pcs.	
	M8 output terminal screws	M8 x 16 : 2 sets (bolts, nuts, and spring washers)	

- \*1. 100 % of the rated output current at an ambient temperature of +45 °C (L type) or 40 °C (H type). Decreases linearly down to 80 % of the rated output current at an ambient temperature of +50 °C.
- \*2. Under packaged condition.
- \*3. With thermal-sensing control (FAN control).
- \*4. Not applicable to custom order models.
- \*5. Only on models that have CE marking on the panel.
- \*6. The power cord that comes standard with the unit is for a rated voltage of 125 Vac (250 Vac for the 1600 W type).  
The PWR operates using a nominal supply voltage in the range of 100 Vac to 240 Vac without switching. However, if the 400 W or 800 W type is used under a supply voltage outside the 100 Vac to 120 Vac range, an appropriate rated power cord must be prepared.  
The power cord included in the package may vary from the specifications due to the shipment destination.

## Model-specific specifications (L type)

		PWR400L	PWR800L	PWR1600L	
Output specifications					
Rating	Rating		400.0 W	800.0 W	1600 W
	Rated output voltage		80.00 V	80.00 V	80.00 V
	Rated output current		25.00 A	50.00 A	100.0 A
Voltage	Maximum preset voltage (typ) <sup>*1</sup>		105 % of rtg		
	Setting accuracy <sup>*2, *3</sup>		0.1 % of rtg + 10 mV		
	Source effect <sup>*3, *4</sup>		0.05 % of rtg + 3 mV		
	Load effect <sup>*5, *3</sup>		0.05 % of rtg + 5 mV		
	Transient response <sup>*6</sup>		1 ms	1.5 ms	2 ms
	Ripple noise <sup>*3</sup>	(p-p) <sup>*7</sup>	60 mV	80 mV	120 mV
		(RMS) <sup>*8</sup>	10 mV	15 mV	20 mV
	Rise time (MAX) <sup>*9</sup>		100 ms [50 ms] (rated load) 100 ms [50 ms] (no load)		
	Fall time (MAX) <sup>*10</sup>		100 ms [40 ms] (rated load) 250 ms [125 ms] (no load)		
	Temperature coefficient (MAX) <sup>*11</sup>		100 ppm/°C (during external analog control)		
Current	Maximum preset current (typ) <sup>*12</sup>		40.0 A	80.0 A	160.0 A
	Setting accuracy <sup>*2, *3</sup>		0.5 % of rtg + 20 mA	0.5 % of rtg + 40 mA	0.5 % of rtg + 80 mA
	Source effect <sup>*3, *4</sup>		0.1 % of rtg + 10 mA		
	Load effect <sup>*3, *13</sup>		0.1 % of rtg + 10 mA		
	Ripple noise (RMS) <sup>*8</sup>		40 mA	80 mA	160 mA
	Temperature coefficient (typ) <sup>*11</sup>		200 ppm/°C (during external control)		
	Maximum output current (typ) <sup>*14</sup>	Continuous	30.00 A	60.00 A	120.0 A
Intermittent		40.00 A	80.00 A	160.0 A	
Parallel/serial operation					
Master-slave parallel operation <sup>*15</sup>		Up to 5 units including the master unit (same models only).			
Master-slave series operation <sup>*16</sup>		Up to 2 units including the master unit (same models only).			

\*1. The maximum preset voltage is provided for establishing a rated output voltage setting. It does not guarantee power supply to the load exceeding the rated output voltage.

\*2. The difference between the actual output voltage (or output current) and the preset value under constant voltage (or constant current) operation.

\*3. Within the rated output current.


\*4. Output voltage (or output current) fluctuation with respect to 10 % fluctuation of the nominal input voltage (ex. 100 Vac) under constant voltage (or constant current) operation.

- \*5. Output voltage fluctuation when the output voltage is set to the rated output voltage and the load is changed from rated load to no load (open load) under constant voltage operation.
- \*6. The time it takes for the output voltage fluctuation to recover from outside 0.1 % + 10 mV of the output voltage setting to within 0.1 % + 10 mV when the output voltage is set to the rated output voltage and the output current is changed from 100 % to 50 % or 50 % to 100 % of the maximum output current at the rated output voltage under constant voltage operation.  
The output voltage when the output current is 100 % is used as a reference.
- \*7. At a measurement frequency bandwidth of 10 Hz to 20 MHz.
- \*8. At a measurement frequency bandwidth of 5 Hz to 1 MHz.
- \*9. The time it takes for the output voltage to rise from 10 % to 90 % of the rating when the output is turned on.  
Set the output current to the rated value. Values inside brackets are typical values.
- \*10. The time it takes for the output voltage to fall from 90 % to 10 % of the rating when the output is turned off.  
Set the output current to the rated value. Values inside brackets are typical values.
- \*11. At an ambient temperature range of 0 °C to 50 °C. The temperature characteristics of the external analog control signal are excluded.
- \*12. To set the current to a value greater than 105 % of the rated output current, turn the setting knob while holding down the SHIFT switch. You do not have to hold down the SHIFT switch if you are lowering the current down from a value greater than 105 % of the rated output current.
- \*13. Output current fluctuation when the output current is set to the rated output current and the load is changed from rated load to no load under constant current operation.
- \*14. The range between the rated output current and the maximum output current (maximum preset current) is the extended operating area. Specifications such as the power supply fluctuation, load fluctuation, ripple noise, and transient response are not met in the extended operating area. The ALM indicator blinks when operating in the extended operating area. In this case, the alarm signal is not output.  
Continuous extended operating area (up to 120 % of the rated output current)  
Continuous output is possible. However, at ambient temperatures greater than or equal to 30 °C, the output current must be derated with respect to the temperature.  
Intermittent extended operating area (120 % to 160 % of the rated output current)  
The maximum output duration is limited to 10 minutes. Pause duration of at least twice the output duration is required.  
For detail, see section X 2.4.2 Extended operating area (L type only)."
- \*15. The difference in the output current between the master unit and the slave unit is within approximately 3 % of the rating.
- \*16. The difference in the output voltage between the master unit and the slave unit is within approximately 3 % of the rating.

		PWR400L	PWR800L	PWR1600L
Input specifications				
Current (MAX) <sup>*1</sup>	100 VAC	6.5 A	13.0 A	26.0 A
	200 VAC	3.3 A	6.5 A	13.0 A
Inrush current (MAX) <sup>*2</sup>		35 Apeak	70 Apeak	140 Apeak
Power (MAX) <sup>*1</sup>		650 VA	1300 VA	2600 VA
Power factor (typ) <sup>*3</sup>		0.980		
Efficiency (MIN) <sup>*4</sup>		70 %		
		PWR400L	PWR800L	PWR1600L
General				
Weight <sup>*5</sup>		Approx. 5 kg (11.02 lbs)	Approx. 8 kg (17.64 lbs)	Approx. 15 kg (33.07 lbs)
Dimensions		See Outline Drawing.		

- \*1. Under rated load. Excludes the extended operating area.
- \*2. Excludes the charge current component that flows through the capacitor of the internal EMC filter circuit immediately after the POWER switch is turned on (within approximately 1 ms).
- \*3. Standard value at an input voltage of 100 Vac under rated load. Excludes the extended operating area.
- \*4. At an input voltage of 100 Vac under rated load. Excludes the extended operating area.
- \*5. Unit only. Does not include accessories.





## Model-specific Specifications (M type)

		PWR400M	PWR800M	PWR1600M	
Output specifications					
Rating	Rating	400.0 W	800.0 W	1600 W	
	Rated output voltage	320.0 V	320.0 V	320.0 V	
	Rated output current	6.250 A	12.50 A	25.000 A	
Voltage	Maximum preset voltage (typ) <sup>*1</sup>	105 % of rtg			
	Setting accuracy <sup>*2, *3</sup>	0.1 % of rtg + 10 mV			
	Source effect <sup>*3, *4</sup>	0.05 % of rtg + 3 mV			
	Load effect <sup>*5, *3</sup>	0.05 % of rtg + 5 mV			
	Transient response <sup>*6</sup>	4 ms	8 ms	12 ms	
	Ripple noise <sup>*3</sup>	(p-p) <sup>*7</sup>	90 mV	140 mV	190 mV
		(RMS) <sup>*8</sup>	15 mV	20 mV	25 mV
	Rise time (MAX) <sup>*9</sup>	160 ms [80 ms] (rated load) 160 ms [80 ms] (no load)			
	Fall time (MAX) <sup>*10</sup>	560 ms [280 ms] (rated load) 2200 ms [14000 ms] (no load)			
	Temperature coefficient (MAX) <sup>*11</sup>	100 ppm/°C (during external control)			
Current	Maximum preset current (typ) <sup>*12</sup>	105 % of rtg			
	Setting accuracy <sup>*2, *3</sup>	0.5 % of rtg + 5 mA	0.5 % of rtg + 10 mA	0.5 % of rtg + 20 mA	
	Source effect <sup>*3A*4</sup>	0.1 % of rtg + 10 mA			
	Load effect <sup>*3, *13</sup>	0.1 % of rtg + 10 mA			
	Ripple noise (RMS) <sup>*8</sup>	25 mA	35 mA	50 mA	
	Temperature coefficient (typ) <sup>*11</sup>	200 ppm/°C (during external control)			
Parallel/serial operation					
Master-slave parallel operation <sup>*14</sup>		Up to 5 units including the master unit (same models only).			
Master-Slave Series Operation		Not allowed			
Input specifications					
Current (MAX) <sup>*15</sup>	100 VAC	6.25 A	12.5 A	25.0 A	
	200 VAC	3.13 A	6.25 A	12.5 A	
Inrush current (MAX) <sup>*16</sup>		35 Apeak	70 Apeak	140 Apeak	
Power (MAX) <sup>*15</sup>		625 VA	1250 VA	2500 VA	
Power factor (typ) <sup>*17</sup>		0.980			
Efficiency (MIN) <sup>*18</sup>		70 %			

	PWR400M	PWR800M	PWR1600M
General (cont.)			
Weight <sup>*19</sup>	Approx. 5 kg (11.02 lbs)	Approx. 8 kg (17.64 lbs)	Approx. 15 kg (33.07 lbs)
Dimensions	See Outline Drawing.		

- \*1. The maximum preset voltage is provided for establishing a rated output voltage setting. It does not guarantee power supply to the load exceeding the rated output voltage.
- \*2. The difference between the actual output voltage (or output current) and the preset value under constant voltage (or constant current) operation.
- \*3. Within the rated output current.
- \*4. Output voltage (or output current) fluctuation with respect to  $\pm 10\%$  fluctuation of the nominal input voltage (ex. 100 Vac) under constant voltage (or constant current) operation.
- \*5. Output voltage fluctuation when the output voltage is set to the rated output voltage and the load is changed from rated load to no load (open load) under constant voltage operation.
- \*6. The time it takes for the output voltage fluctuation to recover from outside  $0.1\% + 10\text{ mV}$  of the output voltage setting to within  $0.1\% + 10\text{ mV}$  when the output voltage is set to the rated output voltage and the output current is changed from  $100\%$  to  $50\%$  or  $50\%$  to  $100\%$  of the maximum output current at the rated output voltage under constant voltage operation.  
The output voltage when the output current is  $100\%$  is used as a reference.
- \*7. At a measurement frequency bandwidth of 10 Hz to 20 MHz.
- \*8. At a measurement frequency bandwidth of 5 Hz to 1 MHz.
- \*9. The time it takes for the output voltage to rise from  $10\%$  to  $90\%$  of the rating when the output is turned on.  
Set the output current to the rated value. Values inside brackets are typical values.
- \*10. The time it takes for the output voltage to fall from  $90\%$  to  $10\%$  of the rating when the output is turned off.  
Set the output current to the rated value. Values inside brackets are typical values..
- \*11. At an ambient temperature range of  $0\text{ }^{\circ}\text{C}$  to  $50\text{ }^{\circ}\text{C}$ . The temperature characteristics of the external analog control signal are excluded.
- \*12. The maximum preset current is provided for establishing a rated output voltage current. It does not guarantee power supply to the load exceeding the rated output current.
- \*13. Output current fluctuation when the output current is set to the rated output current and the load is changed from rated load to no load under constant current operation.
- \*14. The difference in the output current between the master unit and the slave unit is within approximately  $3\%$  of the rating.
- \*15. Under rated load.
- \*16. Excludes the charge current component that flows through the capacitor of the internal EMC filter circuit immediately after the POWER switch is turned on (within approximately 1 ms).
- \*17. Standard value at an input voltage of 100 Vac under rated load.
- \*18. At an input voltage of 100 Vac under rated load.
- \*19. Unit only. Does not include accessories.

## Model-specific specifications (H type)

		PWR400H	PWR800H	PWR1600H	
Output specifications					
Rating	Rating	400.0 W	800.0 W	1600 W	
	Rated output voltage	650.0 V	650.0 V	650.0 V	
	Rated output current	2.000 A	4.000 A	8.000 A	
Voltage	Maximum preset voltage (typ) <sup>*1</sup>	105 % of rtg			
	Setting accuracy <sup>*2, *3</sup>	0.1 % of rtg + 10 mV			
	Source effect <sup>*3, *4</sup>	0.05 % of rtg + 3 mV			
	Load effect <sup>*5, *3</sup>	0.05 % of rtg + 5 mV			
	Transient response <sup>*6</sup>	6 ms	7 ms	8 ms	
	Ripple noise <sup>*3</sup>	(p-p) <sup>*7</sup>	140 mV	210 mV	280 mV
		(RMS) <sup>*8</sup>	20 mV	30 mV	40 mV
	Rise time (MAX) <sup>*9</sup>	260 ms [130 ms] (rated load) 260 ms [130 ms] (no load)			
	Fall time (MAX) <sup>*10</sup>	640 ms [340 ms] (rated load) 2600 ms [1600 ms] (no load)			
	Temperature coefficient (MAX) <sup>*11</sup>	100 ppm/°C (during external control)			
Current	Maximum preset current (typ) <sup>*12</sup>	105 % of rtg			
	Setting accuracy <sup>*2, *3</sup>	0.5 % of rtg + 20 mA	0.5 % of rtg + 40 mA	0.5 % of rtg + 80 mA	
	Source effect <sup>*3A*4</sup>	0.1 % of rtg + 10 mA			
	Load effect <sup>*3, *13</sup>	0.1 % of rtg + 10 mA			
	Ripple noise (RMS) <sup>*8</sup>	10 mA	20 mA	40 mA	
	Temperature coefficient (typ) <sup>*11</sup>	200 ppm/°C (during external control)			
Parallel/serial operation					
Master-slave parallel operation <sup>*14</sup>		Up to 5 units including the master unit (same models only).			
Master-Slave Series Operation		Not allowed			
Input specifications					
Current (MAX) <sup>*15</sup>	100 VAC	6.0 A	12.0 A	24.0 A	
	200 VAC	3.0 A	6.0 A	12.0 A	
Inrush current (MAX) <sup>*16</sup>		35 Apeak	70 Apeak	140 Apeak	
Power (MAX) <sup>*15</sup>		600 VA	1200 VA	2400 VA	
Power factor (typ) <sup>*17</sup>		0.980			
Efficiency (MIN) <sup>*18</sup>		70 %			



	PWR400H	PWR800H	PWR1600H
General (cont.)			
Weight* <sup>19</sup>	Approx. 5 kg (11.02 lbs)	Approx. 8 kg (17.64 lbs)	Approx. 15 kg (33.07 lbs)
Dimensions	See Outline Drawing.		

- \*1. The maximum preset voltage is provided for establishing a rated output voltage setting. It does not guarantee power supply to the load exceeding the rated output voltage.
- \*2. The difference between the actual output voltage (or output current) and the preset value under constant voltage (or constant current) operation.
- \*3. Within the rated output current.
- \*4. Output voltage (or output current) fluctuation with respect to  $\pm 10\%$  fluctuation of the nominal input voltage (ex. 100 Vac) under constant voltage (or constant current) operation.
- \*5. Output voltage fluctuation when the output voltage is set to the rated output voltage and the load is changed from rated load to no load (open load) under constant voltage operation.
- \*6. The time it takes for the output voltage fluctuation to recover from outside  $0.1\% + 10\text{ mV}$  of the output voltage setting to within  $0.1\% + 10\text{ mV}$  when the output voltage is set to the rated output voltage and the output current is changed from  $100\%$  to  $50\%$  or  $50\%$  to  $100\%$  of the maximum output current at the rated output voltage under constant voltage operation.  
The output voltage when the output current is  $100\%$  is used as a reference.
- \*7. At a measurement frequency bandwidth of 10 Hz to 20 MHz.
- \*8. At a measurement frequency bandwidth of 5 Hz to 1 MHz.
- \*9. The time it takes for the output voltage to rise from  $10\%$  to  $90\%$  of the rating when the output is turned on.  
Set the output current to the rated value. Values inside brackets are typical values.
- \*10. The time it takes for the output voltage to fall from  $90\%$  to  $10\%$  of the rating when the output is turned off.  
Set the output current to the rated value. Values inside brackets are typical values..
- \*11. At an ambient temperature range of  $0\text{ }^{\circ}\text{C}$  to  $50\text{ }^{\circ}\text{C}$ . The temperature characteristics of the external analog control signal are excluded.
- \*12. The maximum preset current is provided for establishing a rated output voltage current. It does not guarantee power supply to the load exceeding the rated output current.
- \*13. Output current fluctuation when the output current is set to the rated output current and the load is changed from rated load to no load under constant current operation.
- \*14. The difference in the output current between the master unit and the slave unit is within approximately  $3\%$  of the rating.
- \*15. Under rated load.
- \*16. Excludes the charge current component that flows through the capacitor of the internal EMC filter circuit immediately after the POWER switch is turned on (within approximately 1 ms).
- \*17. Standard value at an input voltage of 100 Vac under rated load.
- \*18. At an input voltage of 100 Vac under rated load.
- \*19. Unit only. Does not include accessories.

## Outline Drawing







Fig. 6-1 400 W type outline drawing



Unit: mm (inch)

Fig. 6-2 800 W type outline drawing



Unit: mm (inch)

Fig. 6-3 1600 W type outline drawing



# Index

## A

- alarm
  - occurrence 2-15
  - signal 2-16
- Analog remote control connector kit 1-5

## B

- breaker trip setting when the protection function trips 2-27

## C

- calibration 5-5
- CC control source setting. 2-25
- CC mode 2-8
- cleaning 5-2
- CONFIG settings 2-23
- constant current mode 2-8
- constant current power supply 2-8
- constant voltage mode 2-8
- constant voltage power supply 2-8
- crossover point 2-10
- current calibration 5-9
- current, setting of 2-13
- CV mode 2-8

## D

- derating 2-11
- derating of the output current 2-12
- dust filter 5-3

## E

- extended operating area 2-7, 2-11
- external control logic of the output
  - on/off 2-26
- external monitoring 3-23
- external resistance 3-12, 3-16

- external voltage 3-10, 3-14

## F

- factory default settings 2-32
- feet, removing of 1-7

## H

- handle, removing of 1-7

## I

- initialization 2-32

## J

- J1 connector 3-2

## L

- lock function 2-28

## M

- master unit 4-2
- master-slave
  - parallel operation 4-8
  - series operation 4-2
- master-slave operation setting 2-26
- maximum output current 2-11
- measured value display 2-2

## O

- OCP 2-17
  - calibration 5-11
- OHP 2-21
- OP01-PAS 1-5
- OPP 2-21
- options 1-3
- outline drawing 6-16

---

- output current, setting of 2-13
- output on/off control 3-18
- output status setting at power-on.
  - 2-26
- output terminal insulation 3-6
- output voltage, setting of 2-13
- overcurrent protection 2-17
  - calibration 5-11
- overheat protection 2-21
- overpower protection 2-21
- overvoltage protection 2-17
  - calibration 5-8
- OVP 2-17
  - calibration 5-8

## P

- panel control 2-4
- PIA3200 1-8
- PL 2-22
- power display 2-2
- POWER LIMIT 2-22
- power limit 2-22
- power supply controller 1-8

## R

- rack mount frame 1-3
  - attachment of 1-6
- rated operating area 2-7
- remote sensing 2-29
  - setting 2-25

## S

- setting display 2-3
- SHUT 2-22
- shutdown 2-22
- shutdown control 3-21
- slave unit 4-2
- specifications
  - common 6-3
  - H type 6-14
  - L type 6-8
  - M type 6-12

- status signal setting of the power on/off 2-27

## T

- termination 2-27
- Troubleshooting 5-12

## V

- version 1-2
- voltage calibration 5-6
- voltage, setting of 2-13





